

Information for Replacement of
FR-A500(L) Series with FR-A800 Series
(375K, 450K)

Size, connection, parameters, options concerning replacement are stated on the following pages.

1. REPLACING INVERTER

The FR-A800 series inverter 315K to 500K is a separated converter type, which consists of an inverter unit (FR-A842) and a converter unit (FR-CC2).

The FR-A800 series has two specifications types: FM type and CA type.

When replacing the FR-A500L series of the Japanese specifications, select the FM type (FR-A842-□□□K-1).

When the FR-A500L series is replaced with the FR-A800 series, the FR-A800 series does not support some FR-A500L series functions. For the unsupported functions, refer to section 4.2.

2. SIZE

When the FR-A500L series is replaced with the FR-A800 series, the FR-A800 series 315K or higher has different installation size from that of the corresponding FR-A500L series.

For more information about the product size, refer to the outline dimension drawings on the following pages.


Existing inverter	Replacing inverter	Installation size
FR-A540L-375K	FR-A842-355K + FR-CC2-H355K (*)	Different size
	FR-A842-400K + FR-CC2-H400K (*)	
FR-A540L-450K	FR-A842-450K + FR-CC2-H450K	

* Select the inverter according to the capacity of the motor driven by the inverter.
Consider the difference between the inverter rated currents.


Inverter	Rated current
FR-A540L-375K	722 A
FR-A842-355K FR-CC2-H355K	683 A
FR-A842-400K FR-CC2-H400K	770 A

Outline dimension drawings (Unit: mm)


■ FR-A540L-375K




■ FR-A842-355K (Inverter unit)




■ FR-CC2-H355K (Converter unit)




■ FR-A842-400K (Inverter unit)




■ FR-CC2-H400K (Converter unit)




■ FR-A540L-450K



■ FR-A842-450K (Inverter unit)



■ FR-CC2-H450K (Converter unit)



3. WIRING

The wiring of the new inverters can follow the one of the existing inverters as the terminal names between them are almost the same.

Type		A500L terminal name	A842 compatible terminal name	CC2 compatible terminal name
Main circuit		R, S, T	—	R/L1, S/L2, T/L3
		U, V, W	U, V, W	—
		R1, S1	R1/L11, S1/L21	R1/L11, S1/L21
		P/+, PR	—	—
		P/+, N/-	P/+, N/-	P/+, N/-
		P/+, P1	—	P1*1
		PR, PX	—	—
		⊕	⊕	⊕
Control circuit / input signal	Contact	STF	STF	—
		STR	STR	—
		STOP	STP (STOP)	—
		RH	RH	—
		RM	RM	—
		RL	RL	—
		JOG	JOG	—
		RT	RT	—
		AU	AU	—
		CS	CS	—
		MRS	MRS	—
		RES	RES	RES
		SD	SD	SD
		PC	PC	PC
Analog	Frequency setting	10E	10E	—
		10	10	—
		2	2	—
		4	4	—
		1	1	—
		5	5	—
Control circuit output signal	Contact	A, B, C	A1, B1, C1	A1, B1, C1
	Open collector	RUN	RUN	—
		SU	SU	—
		OL	OL	—
		IPF	IPF	IPF
		FU	FU	—
		SE	SE	SE
	Pulse	FM	FM	—
Analog	AM	AM	—	
Communication	RS-485	PU connector	PU connector	PU connector

*1) Connection is not available.

Main circuit terminal layout


The following shows the main circuit terminal layouts of the FR-A500L series and FR-A800 series. The main circuit terminal layout and the position of the earth (ground) terminal may differ depending on the capacity. Check the terminal names and positions before performing wiring.

When the cable used for the FR-A500L series is too short for the FR-A800 series, prepare the longer one.


The terminal screw size may differ depending on the capacity. Check the terminal screw size before performing wiring.

[400 V class]


■ FR-A540L-375K, 450K




Terminals R, S, T,
Detail view.




Terminals U, V, W, P0,
P1, P, N,
Detail view.




■ FR-A842-355K to 450K (Inverter unit)



■ FR-CC2-H355K to H450K (Converter unit)






- *1 Do not install an MCCB across the terminals P/+ and N/- (across terminals P and P/+ or across N and N/-). Connecting the opposite polarity of terminals N/- and P/+ will damage the inverter.
- *2 For the terminal used for the X10 signal input, set "10" in any of **Pr.178 to Pr.189 (input terminal function selection)** to assign the function. (The X10 signal is assigned to the terminal MRS in the initial setting.)
For the X10 signal, NC contact input specification is selected in the initial setting. Set **Pr.599** = "0" to change the input specification to NO contact.
- *3 For the terminal used for the X11 signal input, set "11" in any of **Pr.178 to Pr.189 (input terminal function selection)** to assign the function. For RS-485 or any other communication where the start command is only transmitted once, use the X11 signal to save the operation mode at the time of an instantaneous power failure.
- *4 Always connect the terminal RDA of the converter unit and the terminal MRS (X10) of the inverter, and the terminal SE of the converter unit and the terminal SD (sink logic) of the inverter. Not connecting these terminals may damage the converter unit.


NOTE

- Make sure the power cables are connected to the R/L1, S/L2, and T/L3. (Phase need not be matched.) Never connect the power cable to the U, V, and W of the inverter. Doing so will damage the inverter.
- Connect the motor to U, V, and W of the inverter. (Connect the motor in the correct phase sequence.)
- When wiring the main circuit conductor, tighten a nut from the right side of the conductor. When wiring two wires, place wires on both sides of the conductor. (Refer to the drawing below.) For wiring, use bolts (nuts) provided with the converter unit.




- When wiring cables to the main circuit conductor (R/L1, S/L2, T/L3) of the converter unit (FR-CC2), use the bolts (nuts) for main circuit wiring, which are provided on the front side of the conductor.

FR-CC2-H315K, H355K



Connect the cables here.

FR-CC2-H400K to H500K




Connect the cables here.


Control circuit terminal layout

The following shows the control circuit terminal layouts of the FR-A500L series and the FR-A800 series. The control circuit terminal layout differs between the FR-A500L and the FR-A800 series. Check the terminal names and positions before performing wiring.

■ Control circuit terminal layout of the FR-A500L series



■ Control circuit terminal layout of the FR-A800 series



- *1 This terminal operates as the terminal FM for the FM type, and as the terminal CA for the CA type.
- *2 Represents the terminal STOP.
- *3 The X10 signal is assigned in the initial setting.
- *4 No signal is assigned in the initial setting.

The control circuit terminal block intercompatibility attachment (FR-A8TAT) can be used for installing control circuit terminal blocks of the FR-A500(L) series. However, some restrictions apply for the installation. Refer to the FR-A8TAT Instruction Manual.

◆Wiring method

- Power supply connection

For the control circuit wiring, strip off the sheath of a cable, and use it with a blade terminal. For a single wire, strip off the sheath of the wire and apply directly.

Insert the blade terminal or the single wire into a socket of the terminal.

(1)Strip off the sheath for the below length. If the length of the sheath peeled is too long, a short circuit may occur with neighboring wires. If the length is too short, wires might come off.

Wire the stripped cable after twisting it to prevent it from becoming loose. In addition, do not solder it.


Cable stripping size



(2)Crimp the blade terminal.

Insert wires to a blade terminal, and check that the wires come out for about 0 to 0.5 mm from a sleeve.

Check the condition of the blade terminal after crimping. Do not use a blade terminal of which the crimping is inappropriate, or the face is damaged.



- Blade terminals commercially available (as of February 2012)

Phoenix Contact Co., Ltd.

Cable gauge (mm ²)	Blade terminal model			Crimping tool name
	With insulation sleeve	Without insulation sleeve	For UL wire*1	
0.3	AI 0,5-10WH	—	—	CRIMPFOX 6
0.5	AI 0,5-10WH	—	AI 0,5-10WH-GB	
0.75	AI 0,75-10GY	A 0,75-10	AI 0,75-10GY-GB	
1	AI 1-10RD	A 1-10	AI 1-10RD/1000GB	
1.25, 1.5	AI 1,5-10BK	A 1,5-10	AI 1,5-10BK/1000GB*2	
0.75 (for two wires)	AI-TWIN 2 × 0,75-10GY	—	—	


*1 A blade terminal with an insulation sleeve compatible with the MTW wire which has a thick wire insulation.

*2 Applicable for the terminal A1, B1, C1, A2, B2, C2.


NICHIFU Co., Ltd.

Cable gauge (mm ²)	Blade terminal product number	Insulation product number	Crimping tool product number
0.3 to 0.75	BT 0.75-11	VC 0.75	NH 69

(3)Insert the wires into a socket.



When using a single wire or stranded wires without a blade terminal, push the open/close button all the way down with a flathead screwdriver, and insert the wire.




NOTE

- When using stranded wires without a blade terminal, twist enough to avoid short circuit with a nearby terminals or wires.
- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause an inverter damage or injury.

- Wire removal

Pull the wire while pushing the open/close button all the way down firmly with a flathead screwdriver.



NOTE

- Pulling out the wire forcefully without pushing the open/close button all the way down may damage the terminal block.
- Use a small flathead screwdriver (tip thickness: 0.4 mm/tip width: 2.5 mm).

If a flathead screwdriver with a narrow tip is used, terminal block may be damaged.

Commercially available products (as of February 2012)

Name	Model	Manufacturer
Driver	SZF 0- 0,4 × 2,5	Phoenix Contact Co., Ltd.

- Place the flathead screwdriver vertical to the open/close button. In case the blade tip slips, it may cause an inverter damage or injury.

4. PARAMETER

4. 1. Parameter List

Although most parameter numbers are the same, some setting values differ. Refer to the following table to set the parameters.

List of FR-A800 series parameters compatible with the FR-A500L series

The following table shows the parameter settings required when replacing FR-A500L series inverters with FR-A800 series inverters.

When an FR-A500L series parameter is set to a value other than the initial value, set the corresponding FR-A800 series parameter according to the following table.

When an FR-A500L series parameter is set to an initial value, it is usually not necessary to change the corresponding FR-A800 series parameter setting.

The parameters with Δ are used for adjustment. Set them as required.

The parameter replacement following the table below does not guarantee the inverter characteristics or performance.

The parameter number of the parameters differs from that of the FR-A500L series inverter.

Setting \odot : Set the FR-A500L parameter as it is.

Δ : Change the FR-A500L parameter and set.

\times : Adjust or set the FR-A800 parameter.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
0	Torque boost (manual)	0% to 30%	0.75K or lower: 6% 1.5K to 3.7K: 4% 5.5K to 7.5K: 3% 11K or higher: 2%	0	Torque boost (manual)	0% to 30%	0.75K or lower: 6% 1.5K to 3.7K: 4% 5.5K to 7.5K: 3% 11K to 55K: 2% 75K or higher: 1%	Δ	
1	Maximum frequency	0 to 120 Hz	120 Hz	1	Maximum frequency	0 to 120 Hz	55K or lower: 120 Hz 75K or higher: 60 Hz	\odot	
2	Minimum frequency	0 to 120 Hz	0 Hz	2	Minimum frequency	0 to 120 Hz	0 Hz	\odot	
3	Base frequency	0 to 400 Hz	60 Hz	3	Base frequency	0 to 590 Hz	60 Hz	\odot	
4	Multi-speed setting (high speed)	0 to 400 Hz	60 Hz	4	Multi-speed setting (high speed)	0 to 590 Hz	60 Hz	\odot	
5	Multi-speed setting (middle speed)	0 to 400 Hz	30 Hz	5	Multi-speed setting (middle speed)	0 to 590 Hz	30 Hz	\odot	
6	Multi-speed setting (low speed)	0 to 400 Hz	10 Hz	6	Multi-speed setting (low speed)	0 to 590 Hz	10 Hz	\odot	
7	Acceleration time	0 to 3600 s/ 0 to 360 s	7.5K or lower: 5 s 11K or higher: 15 s	7	Acceleration time	0 to 3600 s	7.5K or lower: 5 s 11K or higher: 15 s	\odot	Changing Pr.21 after setting this parameter will change the set value.
8	Deceleration time	0 to 3600 s/ 0 to 360 s	7.5K or lower: 5 s 11K or higher: 15 s	8	Deceleration time	0 to 3600 s	7.5K or lower: 5 s 11K or higher: 15 s	\odot	Changing Pr.21 after setting this parameter will change the set value.
9	Electronic thermal O/L relay	0 to 500 A	Rated output current	9	Electronic thermal O/L relay	55K or lower: 0 to 500 A 75K or higher: 0 to 3600 A	Rated output current	\odot	Set the rated motor current.
10	DC injection brake operation frequency	0 to 120 Hz, 9999	3 Hz	10	DC injection brake operation frequency	0 to 120 Hz, 9999	3 Hz	\odot	
11	DC injection brake operation time	0 to 10 s, 8888	0.5 s	11	DC injection brake operation time	0 to 10 s, 8888	0.5 s	\odot	
12	DC injection brake voltage	0% to 30%	7.5K or lower: 4% 11K or higher: 2%	12	DC injection brake operation voltage	0% to 30%	7.5K or lower: 4% 11K to 55K: 2% 75K or higher: 1%	Δ	
13	Starting frequency	0 to 60 Hz	0.5 Hz	13	Starting frequency	0 to 60 Hz	0.5 Hz	\odot	
14	Load pattern selection	0 to 5	0	14	Load pattern selection	0 to 5, 12 to 15	0	\odot	
15	Jog frequency	0 to 400 Hz	5 Hz	15	Jog frequency	0 to 590 Hz	5 Hz	\odot	
16	Jog acceleration/deceleration time	0 to 3600 s/ 0 to 360 s	0.5 s	16	Jog acceleration/deceleration time	0 to 3600 s	0.5 s	\odot	Changing Pr.21 after setting this parameter will change the set value.
17	MRS input selection	0, 2	0	17	MRS input selection	0, 2, 4	0	\odot	
18	High-speed maximum frequency	120 to 400 Hz	120 Hz	18	High speed maximum frequency	0 to 590 Hz	55K or lower: 120 Hz 75K or higher: 60 Hz	\odot	
19	Base frequency voltage	0 to 1000 V, 8888, 9999	9999	19	Base frequency voltage	0 to 1000 V, 8888, 9999	9999	\odot	

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
20	Acceleration/deceleration reference frequency	1 to 400 Hz	60 Hz	20	Acceleration/deceleration reference frequency	1 to 590 Hz	60 Hz	⊙	
21	Acceleration/deceleration time increments	0, 1	0	21	Acceleration/deceleration time increments	0, 1	0	⊙	
22	Stall prevention operation level	0% to 200%, 9999	150%	22	Stall prevention operation level	0% to 400%	150%*	△	When the FR-A500L setting is other than "9999", set the same value for the FR-A800. When the FR-A500L setting is "9999", set Pr.810 = "1" and Pr.868 = "4" for the FR-A800.
				810	Torque limit input method selection	0, 1	0	×	
				868	Terminal 1 function assignment	0 to 6, 9999	0	×	
23	Stall prevention operation level compensation factor at double speed	0% to 200%, 9999	9999	23	Stall prevention operation level compensation factor at double speed	0% to 200%, 9999	9999	⊙	
24	Multi-speed setting (speed 4)	0 to 400 Hz, 9999	9999	24	Multi-speed setting (speed 4)	0 to 590 Hz, 9999	9999	⊙	
25	Multi-speed setting (speed 5)	0 to 400 Hz, 9999	9999	25	Multi-speed setting (speed 5)	0 to 590 Hz, 9999	9999	⊙	
26	Multi-speed setting (speed 6)	0 to 400 Hz, 9999	9999	26	Multi-speed setting (speed 6)	0 to 590 Hz, 9999	9999	⊙	
27	Multi-speed setting (speed 7)	0 to 400 Hz, 9999	9999	27	Multi-speed setting (speed 7)	0 to 590 Hz, 9999	9999	⊙	
28	Multi-speed input compensation	0, 1	0	28	Multi-speed input compensation selection	0, 1	0	⊙	
29	Acceleration/deceleration pattern	0, 1, 2, 3	0	29	Acceleration/deceleration pattern selection	0 to 6	0	⊙	
30	Regenerative function selection	0, 1, 2	0	30	Regenerative function selection	2, 10, 11, 102, 110, 111	10	△	Change the FR-A500L setting as follows. 0 → 10. 1 → 11. For other than the above, the FR-A500L setting can be used as is.
31	Frequency jump 1A	0 to 400 Hz, 9999	9999	31	Frequency jump 1A	0 to 590 Hz, 9999	9999	⊙	
32	Frequency jump 1B	0 to 400 Hz, 9999	9999	32	Frequency jump 1B	0 to 590 Hz, 9999	9999	⊙	
33	Frequency jump 2A	0 to 400 Hz, 9999	9999	33	Frequency jump 2A	0 to 590 Hz, 9999	9999	⊙	
34	Frequency jump 2B	0 to 400 Hz, 9999	9999	34	Frequency jump 2B	0 to 590 Hz, 9999	9999	⊙	
35	Frequency jump 3A	0 to 400 Hz, 9999	9999	35	Frequency jump 3A	0 to 590 Hz, 9999	9999	⊙	
36	Frequency jump 3B	0 to 400 Hz, 9999	9999	36	Frequency jump 3B	0 to 590 Hz, 9999	9999	⊙	
37	Speed display	0, 1 to 9998	0	37	Speed display	0, 1 to 9998	0	⊙	When the machine speed display is selected in the parameter frequency setting, select the frequency display to change the setting. After the setting, select the machine speed display again.
41	Up-to-frequency sensitivity	0% to 100%	10%	41	Up-to-frequency sensitivity	0% to 100%	10%	⊙	
42	Output frequency detection	0 to 400 Hz	6 Hz	42	Output frequency detection	0 to 590 Hz	6 Hz	⊙	

* When 150% is set for the rated current of the FR-A540L-375K, set as follows: $150\% \times (\text{A540L rated current}) / (\text{A842 rated current})$. Adjust the setting value for the FR-A842-355K, as the value calculated with the formula is large.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
43	Output frequency detection for reverse rotation	0 to 400 Hz, 9999	9999	43	Output frequency detection for reverse rotation	0 to 590 Hz, 9999	9999	⊙	
44	Second acceleration/deceleration time	0 to 3600 s/ 0 to 360 s	5 s	44	Second acceleration/deceleration time	0 to 3600 s	5 s	⊙	Changing Pr.21 after setting this parameter will change the set value.
45	Second deceleration time	0 to 3600 s/ 0 to 360 s, 9999	9999	45	Second deceleration time	0 to 3600 s, 9999	9999	⊙	Changing Pr.21 after setting this parameter will change the set value.
46	Second torque boost	0% to 30%, 9999	9999	46	Second torque boost	0% to 30%, 9999	9999	⊙	
47	Second V/F (base frequency)	0 to 400 Hz, 9999	9999	47	Second V/F (base frequency)	0 to 590 Hz, 9999	9999	⊙	
48	Second stall prevention operation current	0% to 200%	150%	48	Second stall prevention operation level	0% to 400%	150%*	⊙	
49	Second stall prevention operation frequency	0 to 400 Hz, 9999	0	49	Second stall prevention operation frequency	0 to 590 Hz, 9999	0	⊙	
50	Second output frequency detection	0 to 400 Hz	30 Hz	50	Second output frequency detection	0 to 590 Hz	30 Hz	⊙	
52	DU/PU main display data selection	0 to 20, 22, 23, 24, 25, 100	0	52	Operation panel main monitor selection	0, 5 to 14, 17 to 20, 22 to 35, 38, 40 to 45, 50 to 57, 61, 62, 64, 67, 87 to 98, 100	0	⊙	The setting value "9" cannot be selected with the FR-A800.
53	PU level display data selection	0 to 3, 5 to 14, 17, 18	1	—	—	—	—	×	This parameter is not available for the FR-A800.
54	FM terminal function selection	1 to 3, 5 to 14, 17, 18, 21	1	54	FM/CA terminal function selection	1 to 3, 5 to 14, 17, 18, 21, 24, 32 to 34, 50, 52, 53, 61, 62, 67, 70 87 to 90, 92, 93, 95, 97, 98	1	⊙	The setting value "9" cannot be selected with the FR-A800.
55	Frequency monitoring reference	0 to 400 Hz	60 Hz	55	Frequency monitoring reference	0 to 590 Hz	60 Hz	⊙	
56	Current monitoring reference	0 to 500 A	Rated output current	56	Current monitoring reference	55K or lower: 0 to 500 A 75K or higher: 0 to 3600 A	Rated output current	⊙	
57	Restart coasting time	0, 0.1 to 5 s, 9999	9999	57	Restart coasting time	0, 0.1 to 30 s, 9999	9999	⊙	When Pr.57 of the FR-A500L is not set to "9999", set Pr.57 of the FR-CC2 to "0". If the CS signal is not assigned to any input terminal, the restart operation is enabled at all times by setting Pr.57 in the FR-A800.
58	Restart cushion time	0 to 60 s	1.0 s	58	Restart cushion time	0 to 60 s	1.0 s	⊙	
59	Remote setting function selection	0, 1, 2	0	59	Remote setting function selection	0 to 3, 11 to 13	0	⊙	
60	Intelligent mode selection	0 to 8	0	60	Energy saving control selection	0, 4, 9	0	△	When the FR-A500L setting is "0 or 4", set the same value. When the setting is other than "0 or 4", use Pr.292 for setting the value.
				292	Automatic acceleration/deceleration	0, 1, 3, 5 to 8, 11	0	△	When the FR-A500L setting is "1, 3, 5, 6, 7 or 8", set the same value. When the setting is "2", set Pr.292 = "1", Pr.62 = 180%, and Pr.63 = 180% for the FR-A800.
61	Reference I for intelligent mode	0 to 500 A, 9999	9999	61	Reference current	55K or lower: 0 to 500 A, 9999 75K or higher: 0 to 3600 A, 9999	9999	⊙	When the FR-A540L-375K setting is "9999", set the rated current value of the A540L-375K for the FR-A800. Adjust the setting value for the FR-A842-355K, as the rated current value of the FR-A540-375K is large.
62	Ref. I for intelligent mode accel.	0% to 200%, 9999	9999	62	Reference current value at acceleration	0% to 400%, 9999	9999	⊙	
63	Ref. I for intelligent mode decel.	0% to 200%, 9999	9999	63	Reference current value at deceleration	0% to 400%, 9999	9999	⊙	
64	Starting frequency for elevator mode	0 to 10 Hz, 9999	9999	64	Starting frequency for elevator mode	0 to 10 Hz, 9999	9999	⊙	
65	Retry selection	0 to 5	0	65	Retry selection	0 to 5	0	⊙	

* When 150% is set for the rated current of the FR-A540L-375K, set as follows: $150\% \times (\text{A540L rated current}) / (\text{A842 rated current})$. Adjust the setting value for the FR-A842-355K, as the value calculated with the formula is large.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
66	Stall prevention operation level reduction starting frequency	0 to 400 Hz	60 Hz	66	Stall prevention operation reduction starting frequency	0 to 590 Hz	60 Hz	⊙	
67	Number of retries at alarm occurrence	0 to 10, 101 to 110	0	67	Number of retries at fault occurrence	0 to 10, 101 to 110	0	⊙	Set Pr.67 of the FR-CC2 to match the setting of the FR-A500L.
68	Retry waiting time	0 to 10 s	1 s	68	Retry waiting time	0.1 to 600 s	1 s	⊙	Set Pr.68 of the FR-CC2 to match the setting of the FR-A500L.
69	Retry count display erasure	0	0	69	Retry count display erase	0	0	⊙	Set Pr.69 of the FR-CC2 to match the setting of the FR-A500L.
70	Special regenerative brake duty	0.4K to 1.5K: 0% to 15% 2.2K to 7.5K: 0% to 30% 11K or higher: 0%	0%	—	—	—	—	×	This parameter is not available for the FR-A800.
71	Applied motor	0 to 8, 13 to 18, 20, 23, 24	0	71	Applied motor	0 to 6, 13 to 16, 20, 23, 24, 30, 33, 34, 40, 43, 44, 50, 53, 54, 70, 73, 74, 330, 333, 334, 8090, 8093, 8094, 9090, 9093, 9094	0	△	FR-A500L → FR-A800 The values in parentheses are for when Pr.96 of the FR-A500L is set to "3 or 103". 7 → 5 (3) 8 → 6 (3) 17 → 15 (13) 18 → 16 (13)
72	PWM frequency selection	0 to 15	2	72	PWM frequency selection	55K or lower: 0 to 15 75K or higher: 0 to 6, 25	2	⊙	
73	0-5V/0-10V selection	0 to 5, 10 to 15	1	73	Analog input selection	0 to 7, 10 to 17	1	⊙	
74	Filter time constant	0 to 8	1	74	Input filter time constant	0 to 8	1	⊙	
75	Reset selection/disconnected PU detection/PU stop selection	0 to 3, 14 to 17	14	75	Reset selection/disconnected PU detection/PU stop selection	55K or lower: 0 to 3, 14 to 17 75K or higher: 0 to 3, 14 to 17, 100 to 103, 114 to 117	14	⊙	
76	Alarm code output selection	0, 1, 2, 3	0	76	Fault code output selection	0, 1, 2	0	△	For the FR-A800, Pr.76 cannot be set to "3" because the program operation function was deleted.
77	Parameter write disable selection	0, 1, 2	0	77	Parameter write selection	0, 1, 2	0	⊙	
78	Reverse rotation prevention selection	0, 1, 2	0	78	Reverse rotation prevention selection	0, 1, 2	0	⊙	
79	Operation mode selection	0 to 8	0	79	Operation mode selection	0 to 4, 6, 7	0	△	For the FR-A800, Pr.79 cannot be set to "5" because the program operation function was deleted. When the FR-A500L setting is "8", set "0" for the FR-A800 and assign the X16 signal to the control input terminal.
80	Motor capacity	0.4 to 55 kW, 9999	9999	80	Motor capacity	55K or lower: 0.4 to 55 kW, 9999 75K or higher: 0 to 3600 kW, 9999	9999	⊙	
81	Number of motor poles	2, 4, 6, 12, 14, 16, 9999	9999	81	Number of motor poles	2, 4, 6, 8, 10, 12, 9999	9999	△	The setting values "2 to 6" and "9999" can be set as is, but "12 to 16" must be set after subtracting 10.
(82)	Motor excitation current	0 to ****, 9999	9999	82	Motor excitation current	55K or lower: 0 to 500 A, 9999 75K or higher: 0 to 3600 A, 9999	9999	△	The value can be read when Pr.77 = "801" for the FR-A500L. To use this parameter of the FR-A800, set Pr.71 = "4 or 14" or perform auto tuning again.
83	Rated motor voltage	0 to 1000 V	200 V class: 200 V 400 V class: 400 V	83	Rated motor voltage	0 to 1000 V	200 V class: 200 V 400 V class: 400 V	⊙	
84	Rated motor frequency	50 to 120 Hz	60 Hz	84	Rated motor frequency	10 to 400 Hz, 9999	9999	⊙	
89	Speed control gain	0% to 200%	100%	89	Speed control gain	0% to 200%, 9999	9999	⊙	The value can be read when Pr.77 = "801" for the FR-A500L.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
(90)	Motor constant R1	0 to ****, 9999	9999	90	Motor constant R1	55K or lower: 0 to 50 Ω, 9999 75K or higher: 0 to 400 mΩ, 9999	9999	△	The value can be read when Pr.77 = "801" for the FR-A500L. To use this parameter of the FR-A800, set Pr.71 = "4 or 14" or perform auto tuning again.
(91)	Motor constant R2	0 to ****, 9999	9999	91	Motor constant R2	55K or lower: 0 to 50 Ω, 9999 75K or higher: 0 to 400 mΩ, 9999	9999	△	The value can be read when Pr.77 = "801" for the FR-A500L. To use this parameter of the FR-A800, set Pr.71 = "4 or 14" or perform auto tuning again.
(92)	Motor constant L1	0 to ****, 9999	9999	92	Motor constant L1	55K or lower: 0 to 50 Ω (0 to 1000 mH), 9999 75K or higher: 0 to 3600 mΩ (0 to 400 mH), 9999	9999	△	The value can be read when Pr.77 = "801" for the FR-A500L. To use this parameter of the FR-A800, set Pr.71 = "4 or 14" or perform auto tuning again. For the 75K or higher and Pr.71 = "5, 6, 15, or 16", set after rounding up two decimal places.
(93)	Motor constant L2	0 to ****, 9999	9999	93	Motor constant L2	55K or lower: 0 to 50 Ω (0 to 1000 mH), 9999 75K or higher: 0 to 3600 mΩ (0 to 400 mH), 9999	9999	△	The value can be read when Pr.77 = "801" for the FR-A500L. To use this parameter of the FR-A800, set Pr.71 = "4 or 14" or perform auto tuning again. For the 75K or higher and Pr.71 = "5, 6, 15, or 16", set after rounding up two decimal places.
(94)	Motor constant X	0 to ****, 9999	9999	94	Motor constant X	0% to 100%, 9999	9999	△	The value can be read when Pr.77 = "801" for the FR-A500L. To use this parameter of the FR-A800, set Pr.71 = "4 or 14" or perform auto tuning again.
95	Online auto tuning selection	0, 1	0	95	Online auto tuning selection	0 to 2	0	⊙	
96	Auto tuning setting/status	0, 1, 101	0	96	Auto tuning setting/status	0, 1, 11, 101	0	△	If auto tuning has been performed, perform tuning again as required.
100	V/F1 (first frequency)	0 to 400 Hz, 9999	9999	100	V/F1 (first frequency)	0 to 590 Hz, 9999	9999	⊙	
101	V/F1 (first frequency voltage)	0 to 1000 V	0	101	V/F1 (first frequency voltage)	0 to 1000 V	0 V	⊙	
102	V/F2 (second frequency)	0 to 400 Hz, 9999	9999	102	V/F2 (second frequency)	0 to 590 Hz, 9999	9999	⊙	
103	V/F2 (second frequency voltage)	0 to 1000 V	0	103	V/F2 (second frequency voltage)	0 to 1000 V	0 V	⊙	
104	V/F3 (third frequency)	0 to 400 Hz, 9999	9999	104	V/F3 (third frequency)	0 to 590 Hz, 9999	9999	⊙	
105	V/F3 (third frequency voltage)	0 to 1000 V	0	105	V/F3 (third frequency voltage)	0 to 1000 V	0 V	⊙	
106	V/F4 (fourth frequency)	0 to 400 Hz, 9999	9999	106	V/F4 (fourth frequency)	0 to 590 Hz, 9999	9999	⊙	
107	V/F4 (fourth frequency voltage)	0 to 1000 V	0	107	V/F4 (fourth frequency voltage)	0 to 1000 V	0 V	⊙	
108	V/F5 (fifth frequency)	0 to 400 Hz, 9999	9999	108	V/F5 (fifth frequency)	0 to 590 Hz, 9999	9999	⊙	
109	V/F5 (fifth frequency voltage)	0 to 1000 V	0	109	V/F5 (fifth frequency voltage)	0 to 1000 V	0 V	⊙	
110	Third acceleration/deceleration time	0 to 3600 s/ 0 to 360 s, 9999	9999	110	Third acceleration/deceleration time	0 to 3600 s, 9999	9999	⊙	Changing Pr.21 after setting this parameter will change the set value.
111	Third deceleration time	0 to 3600 s/ 0 to 360 s, 9999	9999	111	Third deceleration time	0 to 3600 s, 9999	9999	⊙	Changing Pr.21 after setting this parameter will change the set value.
112	Third torque boost	0% to 30%, 9999	9999	112	Third torque boost	0% to 30%, 9999	9999	⊙	
113	Third V/F (base frequency)	0 to 400 Hz, 9999	9999	113	Third V/F (base frequency)	0 to 590 Hz, 9999	9999	⊙	
114	Third stall prevention operation current	0% to 200%	150%	114	Third stall prevention operation level	0% to 400%	150%*	⊙	
115	Third stall prevention operation frequency	0 to 400 Hz	0	115	Third stall prevention operation frequency	0 to 590 Hz	0	⊙	
116	Third output frequency detection	0 to 400 Hz, 9999	9999	116	Third output frequency detection	0 to 590 Hz	60 Hz	△	When the FR-A500L setting is "9999", use the initial setting for the FR-A800.
117	Communication station number	0 to 31	0	117	PU communication station number	0 to 31	0	⊙	
118	Communication speed	48, 96, 192	192	118	PU communication speed	48, 96, 192, 384, 576, 768, 1152	192	⊙	
119	Stop bit length / data length	0, 1, 10, 11	1	119	PU communication stop bit length	0, 1, 10, 11	1	⊙	
120	Parity check presence/absence	0, 1, 2	2	120	PU communication parity check	0, 1, 2	2	⊙	
121	Number of communication retries	0 to 10, 9999	1	121	PU communication retry count	0 to 10, 9999	1	⊙	
122	Communication check time interval	0, 0.1 to 999.8 s, 9999	0	122	PU communication check time interval	0, 0.1 to 999.8 s, 9999	9999	△	The initial value for the FR-A800 has been changed.

* When 150% is set for the rated current of the FR-A540L-375K, set as follows: $150\% \times (\text{A540L rated current}) / (\text{A842 rated current})$. Adjust the setting value for the FR-A842-355K, as the value calculated with the formula is large.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
123	Waiting time setting	0 to 150 ms, 9999	9999	123	PU communication waiting time setting	0 to 150 ms, 9999	9999	⊙	
124	CR, LF presence/absence selection	0, 1, 2	1	124	PU communication CR/LF selection	0, 1, 2	1	⊙	
128	PID action selection	10, 11, 20, 21	10	128	PID action selection	0, 10, 11, 20, 21, 40 to 43, 50, 51, 60, 61, 70, 71, 80, 81, 90, 91, 100, 101, 1000, 1001, 1010, 1011, 2000, 2001, 2010, 2011	0	△	When "14" (X14 signal) is not set in any parameter from Pr.180 to Pr.186, or when PID control is not used even if "14" (X14 signal) is set in any parameter from Pr.180 to Pr.186 in the FR-A800, set "0" in Pr.128 in the FR-A800. When the X14 signal is not assigned to any input terminal, just set a value in Pr.128 to enable PID control in the FR-A800.
129	PID proportional band	0.1% to 1000%, 9999	100%	129	PID proportional band	0.1% to 1000%, 9999	100%	⊙	
130	PID integral time	0.1 to 3600 s, 9999	1 s	130	PID integral time	0.1 to 3600 s, 9999	1 s	⊙	
131	Upper limit	0% to 100%, 9999	9999	131	PID upper limit	0% to 100%, 9999	9999	⊙	
132	Lower limit	0% to 100%, 9999	9999	132	PID lower limit	0% to 100%, 9999	9999	⊙	
133	PID action set point for PU operation	0% to 100%	0%	133	PID action set point	0% to 100%, 9999	9999	△	To use the value input via terminal 2 as a set point for the FR-A800 inverters, set "9999". When the value other than "9999" is set, the set value will be also used as a set point during operations other than the PU operation.
134	PID differential time	0.01 to 10.00 s, 9999	9999	134	PID differential time	0.01 to 10.00 s, 9999	9999	⊙	
135	Commercial power supply-inverter switch-over sequence output terminal selection	0, 1	0	135	Electronic bypass sequence selection	0, 1	0	⊙	
136	MC switchover interlock time	0 to 100.0 s	1.0 s	136	MC switchover interlock time	0 to 100.0 s	1.0 s	⊙	
137	Start waiting time	0 to 100.0 s	0.5 s	137	Start waiting time	0 to 100.0 s	0.5 s	⊙	
138	Commercial power supply-inverter switch-over selection at alarm occurrence	0, 1	0	138	Bypass selection at a fault	0, 1	0	⊙	
139	Automatic inverter-commercial power supply switch-over frequency	0 to 60.00 Hz, 9999	9999	139	Automatic switchover frequency from inverter to bypass operation	0 to 60.00 Hz, 9999	9999	⊙	
140	Backlash acceleration stopping frequency	0 to 400 Hz	1 Hz	140	Backlash acceleration stopping frequency	0 to 590 Hz	1 Hz	⊙	The setting is valid when Pr.29 = "3".
141	Backlash acceleration stopping time	0 to 360 s	0.5 s	141	Backlash acceleration stopping time	0 to 360 s	0.5 s	⊙	The setting is valid when Pr.29 = "3".
142	Backlash deceleration stopping frequency	0 to 400 Hz	1 Hz	142	Backlash deceleration stopping frequency	0 to 590 Hz	1 Hz	⊙	The setting is valid when Pr.29 = "3".
143	Backlash deceleration stopping time	0 to 360 s	0.5 s	143	Backlash deceleration stopping time	0 to 360 s	0.5 s	⊙	The setting is valid when Pr.29 = "3".
144	Speed setting switch-over	0, 2, 4, 6, 8, 10, 102, 104, 106, 108, 110	4	144	Speed setting switchover	0, 2, 4, 6, 8, 10, 102, 104, 106, 108, 110, 112	4	⊙	
145	PU display language selection	0 to 7	0	145	PU display language selection	0 to 7	1	△	The initial value for the FR-A800 has been changed.
148	Stall prevention operation level at 0V input	0% to 200%	150%	148	Stall prevention level at 0 V input	0% to 400%	150%*	⊙	
149	Stall prevention operation level at 10V input	0% to 200%	200%	149	Stall prevention level at 10 V input	0% to 400%	200%*	⊙	
150	Output current detection level	0% to 200%	150%	150	Output current detection level	0% to 400%	150%*	⊙	
151	Output current detection period	0 to 10 s	0	151	Output current detection signal delay time	0 to 10 s	0	⊙	
152	Zero current detection level	0% to 200%	5.0%	152	Zero current detection level	0% to 400%	5%*	⊙	
153	Zero current detection period	0 to 1 s	0.5 s	153	Zero current detection time	0 to 10 s	0.5 s	⊙	
154	Voltage reduction selection during stall prevention operation	0, 1	1	154	Voltage reduction selection during stall prevention operation	0, 1, 10, 11	1	⊙	
155	RT signal activated condition	0, 10	0	155	RT signal function validity condition selection	0, 10	0	⊙	
156	Stall prevention operation selection	0 to 31, 100, 101	0	156	Stall prevention operation selection	0 to 31, 100, 101	0	⊙	
157	OL signal waiting time	0 to 25 s, 9999	0	157	OL signal output timer	0 to 25 s, 9999	0 s	⊙	
158	AM terminal function selection	1 to 3, 5 to 14, 17, 18, 21	1	158	AM terminal function selection	1 to 3, 5 to 14, 17, 18, 21, 24, 32 to 34, 50, 52 to 54, 61, 62, 67, 70, 87 to 90, 91 to 98	1	⊙	The setting value "9" cannot be selected with the FR-A800.

* When 150% is set for the rated current of the FR-A540L-375K, set as follows: $150\% \times (\text{A540L rated current}) / (\text{A842 rated current})$. Adjust the setting value for the FR-A842-355K, as the value calculated with the formula is large.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting		
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks	
160	User group read selection	0, 1, 10, 11	0	160	User group read selection	0, 1, 9999	0	△	The user group 2 was deleted for the FR-A800.	
162	Automatic restart after instantaneous power failure selection	0, 1	0	162	Automatic restart after instantaneous power failure selection	0 to 3, 10 to 13	0	⊙		
163	First cushion time for restart	0 to 20 s	0 s	163	First cushion time for restart	0 to 20 s	0 s	⊙		
164	First cushion voltage for restart	0% to 100%	0%	164	First cushion voltage for restart	0% to 100%	0%	⊙		
165	Restart stall prevention operation level	0% to 200%	150%	165	Stall prevention operation level for restart	0% to 400%	150%*	⊙		
170	Watt-hour meter clear	0	0	170	Watt-hour meter clear	0, 10, 9999	9999	×	Setting not required	
171	Actual operation hour meter clear	0	0	171	Operation hour meter clear	0, 9999	9999	×	Setting not required	
173	User group 1 registration	0 to 999	0	173	User group registration	0 to 1999, 9999	9999	×	Set the parameter as required.	
174	User group 1 deletion	0 to 999, 9999	0	174	User group clear	0 to 1999, 9999	9999	×		
175	User group 2 registration	0 to 999	0	—				×	Not available for the FR-A800	
176	User group 2 deletion	0 to 999, 9999	0	—				×	Not available for the FR-A800	
180	RL terminal function selection	0 to 99, 9999	0	180	RL terminal function selection	0 to 20, 22 to 28, 37, 42 to 47, 50, 51, 62, 64 to 69, 72 to 74, 76 to 80, 87, 92 to 96, 9999	0	⊙	The setting values "70 and 71" cannot be selected with the FR-A800.	
181	RM terminal function selection	0 to 99, 9999	1	181	RM terminal function selection		1	⊙	The setting values "70 and 71" cannot be selected with the FR-A800.	
182	RH terminal function selection	0 to 99, 9999	2	182	RH terminal function selection		2	⊙	The setting values "70 and 71" cannot be selected with the FR-A800.	
183	RT terminal function selection	0 to 99, 9999	3	183	RT terminal function selection		3	⊙	The setting values "70 and 71" cannot be selected with the FR-A800.	
184	AU terminal function selection	0 to 99, 9999	4	184	AU terminal function selection		4	⊙	The setting values "70 and 71" cannot be selected with the FR-A800.	
185	JOG terminal function selection	0 to 99, 9999	5	185	JOG terminal function selection		5	⊙	The setting values "70 and 71" cannot be selected with the FR-A800.	
186	CS terminal function selection	0 to 99, 9999	6	186	CS terminal function selection		6	⊙	The setting values "70 and 71" cannot be selected with the FR-A800.	
—	—	—	—	187	MRS terminal function selection		10	△	The setting values "70 and 71" cannot be selected with the FR-A800. Change the setting to "10" to enable output shutoff when disconnection occurs while the output enable signal (RDY) from the FR-CC2 is connected.	
190	RUN terminal function selection	0 to 199, 9999	0	190	RUN terminal function selection	0 to 8, 10 to 20, 22, 25 to 28, 30 to 36, 38 to 54, 56, 57, 60, 61, 63, 64, 67, 68, 70, 79, 84, 85, 90 to 99, 100 to 108, 110 to 116, 120, 122, 125 to 128, 130 to 136, 138 to 154, 156, 157, 160, 161, 163, 164, 167, 168, 170, 179, 184, 185, 190 to 199, 200 to 208, 300 to 308, 9999	0	⊙	The setting values "2, 7, 46, 85, 87, 89, 102, 107, 146, 185, 187, and 189" cannot be selected with the FR-A800.	
191	SU terminal function selection	0 to 199, 9999	1	191	SU terminal function selection		1	⊙		
192	IPF terminal function selection	0 to 199, 9999	2	192	IPF terminal function selection		9999	△		When "2 or 102" is set for the FR-A500L, set the value for the FR-A800 using the FR-CC2.
193	OL terminal function selection	0 to 199, 9999	3	193	OL terminal function selection		3	⊙		
194	FU terminal function selection	0 to 199, 9999	4	194	FU terminal function selection		4	⊙		
195	A, B, C terminal function selection	0 to 199, 9999	99	195	ABC1 terminal function selection	99	⊙	The setting values "2, 7, 46, 85, 87, 89, 102, 107, 146, 185, 187, and 189" cannot be selected with the FR-A800.		
199	User's initial value setting	0 to 999, 9999	0	—				×	Not available for the FR-A800	
200	Programmed operation minute/second selection	0 to 3	0	—				×	Not available for the FR-A800	
201 to 210	Program set 1, 1 to 10	0 to 2 0 to 400 Hz, 9999 0 to 99.59	0 9999 0	—				×	Not available for the FR-A800	
211 to 220	Program set 2, 11 to 20	0 to 2 0 to 400 Hz, 9999 0 to 99.59	0 9999 0	—				×	Not available for the FR-A800	

* When 150% is set for the rated current of the FR-A540L-375K, set as follows: $150\% \times (\text{A540L rated current}) / (\text{A842 rated current})$. Adjust the setting value for the FR-A842-355K, as the value calculated with the formula is large.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
221 to 230	Program set 3, 21 to 30	0 to 2 0 to 400 Hz, 9999 0 to 99.59	0 9999 0	—				×	Not available for the FR-A800
231	Timer setting	0 to 99.59	0	—				×	Not available for the FR-A800
232	Multi-speed setting (speed 8)	0 to 400 Hz, 9999	9999	232	Multi-speed setting (speed 8)	0 to 590 Hz, 9999	9999	⊙	
233	Multi-speed setting (speed 9)	0 to 400 Hz, 9999	9999	233	Multi-speed setting (speed 9)	0 to 590 Hz, 9999	9999	⊙	
234	Multi-speed setting (speed 10)	0 to 400 Hz, 9999	9999	234	Multi-speed setting (speed 10)	0 to 590 Hz, 9999	9999	⊙	
235	Multi-speed setting (speed 11)	0 to 400 Hz, 9999	9999	235	Multi-speed setting (speed 11)	0 to 590 Hz, 9999	9999	⊙	
236	Multi-speed setting (speed 12)	0 to 400 Hz, 9999	9999	236	Multi-speed setting (speed 12)	0 to 590 Hz, 9999	9999	⊙	
237	Multi-speed setting (speed 13)	0 to 400 Hz, 9999	9999	237	Multi-speed setting (speed 13)	0 to 590 Hz, 9999	9999	⊙	
238	Multi-speed setting (speed 14)	0 to 400 Hz, 9999	9999	238	Multi-speed setting (speed 14)	0 to 590 Hz, 9999	9999	⊙	
239	Multi-speed setting (speed 15)	0 to 400 Hz, 9999	9999	239	Multi-speed setting (speed 15)	0 to 590 Hz, 9999	9999	⊙	
240	Soft-PWM setting	0, 1, 10, 11	1	240	Soft-PWM operation setting	0, 1	1	△	The FR-A800 settings corresponding to the FR-A500L settings are as follows. 0, 10 → 0. 1, 11 → 1.
244	Cooling fan operation selection	0, 1	0	244	Cooling fan operation selection	0, 1, 101 to 105	1	△	The initial value for the FR-A800 has been changed.
250	Stop selection	0 to 100 s, 9999	9999	250	Stop selection	0 to 100 s, 1000 to 1100 s, 8888, 9999	9999	⊙	
251	Output phase failure protection selection	0, 1	1	251	Output phase loss protection selection	0, 1	1	⊙	
252	Override bias	0% to 200%	50%	252	Override bias	0% to 200%	50%	⊙	
253	Override gain	0% to 200%	150%	253	Override gain	0% to 200%	150%	⊙	
261	Power failure stop selection	0, 1	0	261	Power failure stop selection	0, 1, 2, 11, 12, 21, 22	0	△	Setting Pr.261 is required also in the FR-CC2 manufactured in August 2014 or later.
262	Subtracted frequency at deceleration start	0 to 20 Hz	3 Hz	262	Subtracted frequency at deceleration start	0 to 20 Hz	3 Hz	△	
263	Subtraction starting frequency	0 to 120 Hz, 9999	60 Hz	263	Subtraction starting frequency	0 to 590 Hz, 9999	60 Hz	△	Changing Pr.21 after setting Pr.264 and Pr.265 will change the set values.
264	Power-failure deceleration time 1	0 to 3600 s/ 0 to 360 s	5 s	264	Power-failure deceleration time 1	0 to 3600 s	5 s	△	
265	Power-failure deceleration time 2	0 to 3600 s/ 0 to 360 s, 9999	9999	265	Power-failure deceleration time 2	0 to 3600 s, 9999	9999	△	
266	Power failure deceleration time switchover frequency	0 to 400 Hz	60 Hz	266	Power failure deceleration time switchover frequency	0 to 590 Hz	60 Hz	△	
270	Stop-on contact/load torque high-speed frequency control selection	0, 1, 2, 3	0	270	Stop-on contact/load torque high-speed frequency control selection	0, 1, 2, 3, 11, 13	0	⊙	
271	High-speed setting maximum current	0% to 200%	50%	271	High-speed setting maximum current	0% to 400%	50%*	⊙	
272	Mid-speed setting minimum current	0% to 200%	100%	272	Middle-speed setting minimum current	0% to 400%	100%*	⊙	
273	Current averaging range	0 to 400 Hz, 9999	9999	273	Current averaging range	0 to 590 Hz, 9999	9999	⊙	
274	Current averaging filter constant	1 to 4000	16	274	Current averaging filter time constant	1 to 4000	16	⊙	
275	Stop-on contact exciting current low-speed multiplying factor	0% to 1000%, 9999	9999	275	Stop-on contact excitation current low-speed multiplying factor	50% to 300%, 9999	9999	⊙	
276	Stop-on-contact PWM carrier frequency	0 to 15, 9999	9999	276	PWM carrier frequency at stop-on contact	55K or lower: 0 to 9, 9999 75K or higher: 0 to 4, 9999	9999	△	When "9" or more value is set for the FR-A500L, set "9" for the FR-A800.
278	Brake opening frequency	0 to 30 Hz	3 Hz	278	Brake opening frequency	0 to 30 Hz	3 Hz	⊙	
279	Brake opening current	0% to 200%	130%	279	Brake opening current	0% to 400%	130%*	⊙	
280	Brake opening current detection time	0 to 2 s	0.3 s	280	Brake opening current detection time	0 to 2 s	0.3 s	⊙	
281	Brake operation time at start	0 to 5 s	0.3 s	281	Brake operation time at start	0 to 5 s	0.3 s	⊙	

* When 150% is set for the rated current of the FR-A540L-375K, set as follows: $150\% \times (\text{A540L rated current}) / (\text{A842 rated current})$. Adjust the setting value for the FR-A842-355K, as the value calculated with the formula is large.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
282	Brake operation frequency	0 to 30 Hz	6 Hz	282	Brake operation frequency	0 to 30 Hz	6 Hz	⊙	
283	Brake operation time at stop	0 to 5 s	0.3 s	283	Brake operation time at stop	0 to 5 s	0.3 s	⊙	
284	Deceleration detection function selection	0, 1	0	284	Deceleration detection function selection	0, 1	0	⊙	
285	Overspeed detection frequency	0 to 30 Hz, 9999	9999	285	Overspeed detection frequency (Speed deviation excess detection frequency)	0 to 30 Hz, 9999	9999	⊙	
286	Droop gain	0% to 100%	0%	286	Droop gain	0% to 100%	0%	⊙	
287	Droop filter constant	0.00 to 1.00 s	0.3 s	287	Droop filter time constant	0 to 1 s	0.3 s	⊙	
342	E2PROM write selection	0, 1	0	342	Communication EEPROM write selection	0, 1	0	⊙	
503	Capacitor life timer	—	—	503	Maintenance timer 1	0 (1 to 9998)	0	×	Setting not required
504	Capacitor life alarm output set time	0 to 9998, (9999)	876	504	Maintenance timer 1 warning output set time	0 to 9998, 9999	9999	△	When "9999" is set for the FR-A800, the function is disabled. When "9999" is set for the FR-A500L, set "876" for the FR-A800.
611	Restart acceleration time	0 to 3600 s, 9999	5.0 s	611	Acceleration time at a restart	0 to 3600 s, 9999	9999	⊙	
900	FM terminal calibration	—	—	C0 (900)	FM/CA terminal calibration	—	—	×	Calibrate the parameter as required.
901	AM terminal calibration	—	—	C1 (901)	AM terminal calibration	—	—	×	Calibrate the parameter as required.
902	Frequency setting voltage bias	0 to 60 Hz: 0 to 10 V	0 Hz: 0 V	C2 (902)	Terminal 2 frequency setting bias frequency	0 to 590 Hz	0 Hz	△	Set the parameter as required. For the details, refer to section "5.12.5 Frequency setting voltage (current) bias and gain" and "5.12.6 Bias and gain for torque (magnetic flux) and set voltage (current)" of the Instruction Manual (Detailed).
				C3 (902)	Terminal 2 frequency setting bias	0% to 300%	0%	△	
903	Frequency setting voltage gain	1 to 400 Hz: 0 to 10 V	60 Hz: 5 V	125 (903)	Terminal 2 frequency setting gain frequency	0 to 590 Hz	60 Hz	△	
				C4 (903)	Terminal 2 frequency setting gain	0% to 300%	100%	△	
904	Frequency setting current bias	0 to 60 Hz: 0 to 20 mA	0 Hz: 4 mA	C5 (904)	Terminal 4 frequency setting bias frequency	0 to 590 Hz	0 Hz	△	
				C6 (904)	Terminal 4 frequency setting bias	0% to 300%	20%	△	
905	Frequency setting current gain	1 to 400 Hz: 0 to 20 mA	60 Hz: 20 mA	126 (905)	Terminal 4 frequency setting gain frequency	0 to 590 Hz	60 Hz	△	
				C7 (905)	Terminal 4 frequency setting gain	0% to 300%	100%	△	
990	PU buzzer control	0, 1	1	990	PU buzzer control	0, 1	1	⊙	

List of FR-A8NC parameters compatible with the FR-A5NC

The following table shows the parameter settings of the FR-A800 series inverter required when replacing an FR-A5NC with an FR-A8NC.
 When an FR-A500L series parameter is set to a value other than the initial value, set the corresponding FR-A800 parameter according to the following table.
 When an FR-A500L series parameter is set to an initial value, it is usually not necessary to change the corresponding FR-A800 parameter setting.

The parameter number of the parameters differs from that of the FR-A500L series inverter.

Setting ⊙: Set the FR-A500L parameter as it is.

△: Change the FR-A500L parameter and set.

×: Adjust or set the FR-A800 parameter.

FR-A500L parameter list				FR-A800 compatible parameter				Parameter setting	
Pr.	Name	Setting range	Initial value	Pr.	Name	Setting range	Initial value	Setting	Remarks
338	Operation command source	0, 1	0	338	Communication operation command source	0, 1	0	×	The command source of terminals MRS, RES, and terminal 1 differs between the FR-A800 and the FR-A500L.
339	Speed command source	0, 1	0	339	Communication speed command source	0, 1, 2	0		
340	Link startup mode selection	0 to 2, 10, 12, 20, 22	0	340	Communication startup mode selection	0, 1, 2, 10, 12	0	×	The setting values "20 and 22" cannot be used with the FR-A800. Operations differ by the combination of the X66 signal, Pr.79, and Pr.340.
349	Error reset selection during CC-Link communication	0, 1	0	349	Communication reset selection	0, 1	0	⊙	
500	Communication error recognition waiting time	0 to 999.8 s	0 s	500	Communication error execution waiting time	0 to 999.8 s	0 s	⊙	
501	Communication error occurrence count display	0	0	501	Communication error occurrence count display	0	0	⊙	
502	Communication error time stop mode selection	0 to 2	0	502	Stop mode selection at communication error	0 to 3	0	⊙	
				542	Communication station number (CC-Link)	1 to 64	1	×	The station number is set with the station number setting switch for FR-A500L. Use the Pr.542 setting for FR-A800.
				543	Baud rate selection (CC-Link)	0 to 4	0	×	The baud rate is set with the transmission baud rate setting switch for FR-A500L. Use the Pr.543 setting for FR-A800. 0: 156 kbps 1: 625 kbps 2: 2.5 Mbps 3: 5 Mbps 4: 10 Mbps

4. 2. Restrictions for the FR-A800 Series

When the FR-A500L series is replaced with the FR-A800 series, the FR-A800 series does not support some FR-A500L series functions as shown below.

(1) Unsupported functions

No.	Item	Remarks
1	Power failure stop function	This function is available for the FR-CC2 manufactured in August 2014 or later.
2	PU level display data selection	
3	User's initial value setting	
4	Program operation function	
5	User group 2	
6	Special regenerative brake duty	
7	Electronic bypass sequence	When an error occurs in the FR-CC2, the commercial power supply operation is not activated. For the FR-CC2 manufactured in August 2014 or later, use the X95 and X96 signals.
8	Warnings and protective functions	The FR-A842 does not support the regenerative brake pre-alarm (RB) or the brake transistor alarm detection (E.BE).

(2) Functions unsupported by the FR-A842 but supported by the FR-CC2

No.	Item	Remarks
1	Warnings and protective functions	With this function, the FR-CC2 can detect the instantaneous power failure (E.IPF) and the undervoltage (E.UVT).

(3) Other restrictions

No.	No.	Remarks
1	Startup time	If the power to the main circuit of the FR-CC2 is turned ON with the control circuit power already ON, the FR-CC2 performs a reset. The inverter is reset and the startup delays.
2	Operation panel (provided for FR-CC2 only)	Install the operation panel of the FR-A842 to set the FR-CC2.

4. 3. Compatibility of the Terminal Response Speed

The response of the input/output terminals of the FR-A800 series is improved compared to the FR-A500L series. Operation timing of the device may differ depending on the usage.

In this case, set Pr.289 (Inverter output terminal filter) and Pr.699 (Input terminal filter) to adjust the terminal response time.

Set 5 to 8 ms in Pr.289 and Pr.699 and adjust according to the system.

5. OPTION

5. 1. Option

The following table shows which FR-A500L series options are compatible with the FR-A800 series inverters and their corresponding A800 series options.

Name		Option model	
		FR-A500L	FR-A800
Plug-in type	12-bit digital input	FR-A5AX	FR-A8AX The priority for the frequency setting differs between the FR-A500L and the FR-A800. For the details, refer to the Instruction Manual.
	Digital output, additional analog output	FR-A5AY	FR-A8AY
	Relay output	FR-A5AR	FR-A8AR
	Orientation/encoder/pulse train input	FR-A5AP, T-PLG50, T-PLG51	FR-A8AP (The pulse train input is a built-in function of the inverter.)
	Computer link	FR-A5NR	Built-in function of the inverter (RS-485 terminals, two relay output terminals)
	Profibus-DP	FR-A5NP	FR-A8NP
	Device Net	FR-A5ND	FR-A8ND
	CC-Link	FR-A5NC	FR-A8NC
Stand-alone type	Parameter unit	FR-PU04	Not compatible Use FR-PU07.
	Parameter unit connection cable	FR-CB201, 203, 205	Compatible Prepare FR-ADP for installing the operation panel on the enclosure surface.
	EMC Directive compliant noise filter	SF	Built-in function of the inverter (EN 61800-3 2nd Environment compatible)
	Power factor improving AC reactor	MT-BAL-H	Compatible If replacing the reactor, use FR-HAL-(H).
	Radio noise filter	FR-BIF-H	Compatible
	Line noise filter	FR-BLF	Compatible
	Brake unit	FR-BU-H, FR-BU2-H	Compatible MT-BU5 is not compatible.
	Resistor unit	MT-BR5-H	Compatible
	FR-HC type high power factor converter	FR-HC2-H	Compatible
Manual Controller/Speed controller	Manual controller	FR-AX	Compatible
	DC tach. follower	FR-AL	Compatible
	Three speed selector	FR-AT	Compatible
	Motorized speed setter	FR-FK	Compatible
	Ratio setter	FR-FH	Compatible
	Speed detector	FR-FP	Compatible
	Master controller	FR-FG	Compatible
	Soft starter	FR-FC	Compatible
	Deviation detector	FR-FD	Compatible
	Preamplifier	FR-FA	Compatible
Others	Pilot generator	QVAH-10	Compatible
	Deviation sensor	YVGC-500W-NS	Compatible
	Frequency setting potentiometer	WA2W 1 kΩ	Compatible
	Analog frequency meter	YM206NRI 1 mA	Compatible
	Calibration resistor	RV24YN 10 kΩ	Compatible

5. 2. Replacement When the FR-A5NC Is Used

The FR-A5NC (CC-Link communication option) used with the FR-A500L series cannot be used with the FR-A800 series. For the CC-Link communication with the FR-A800 series, use the FR-A8NC.


(1) Shape and installation method

The following table shows the differences in the shape and installation method.

Item	FR-A5NC	FR-A8NC	Remarks
Shape	Inverter plug-in option type, terminal block connection	Inverter plug-in option type, terminal block connection	Although the connection method is the same, the circuit board of the option has a different shape.
Connection terminal block	6-terminal terminal block (M3 × 6 mm screws)	A6CON-L5P Insertion wiring	The shape of the terminal block and wiring method differ. A terminal block is not enclosed.
Installation procedure	Installed to the slot 3 * After installing the front cover, install the terminal block.	Connected to the option connector 1. * After performing wiring to the terminal block, install the front cover.	
Terminating resistor	Terminating resistor supplied with the programmable controller	Terminating resistor selection switch	
Connection cable*1	CC-Link dedicated cable	CC-Link dedicated cable	


*1 Attention must be paid to the connection cable length.

[Shape of the FR-A5NC]



* For the FR-A8NC, the station number and the transmission baud rate are set in the inverter parameters. Read the values set with the station number switch and the transmission baud rate switch of the FR-A5NC, and take a note of them.

[Shape of the FR-A8NC]




Symbol	Name	Description
a	Mounting hole	Fixes the option to the inverter with screws, or installs spacers.
b	CC-Link communication one-touch connector	CC-Link communication can be performed with the CC-Link communication connector.
c	Switch for manufacturer setting	Switch for manufacturer setting. Do not change the initial setting (OFF).
d	Terminating resistor selection switch	Select the resistor value of the terminating resistor.
e	Connector	Connected to the option connector of the inverter.


[Installation procedure of the FR-A8NC]

◆ **Installation of the communication option LED display cover**

- (1) Remove the inverter front cover. (Refer to Chapter 2 of the Instruction Manual (Detailed) of the inverter for details on how to remove the front cover.)
Mount the cover for displaying the operation status indication LED for the communication option on the inverter front cover.
- (2) Cut off hooks on the rear of the inverter front cover with nipper, etc. and open a window for fitting the LED display cover.



- (3) Fit the communication option LED display cover to the front of the inverter front cover and push it into until fixed with hooks.




NOTE


- The protective structure (JEM1030) changes to the open type (IP00).

◆ **Installing the option**

- (1) For the two mounting holes (as shown in the next page) that will not be tightened with mounting screws, insert spacers.
- (2) Fit the connector of the plug-in option to the guide of the connector on the inverter unit side, and insert the plug-in option as far as it goes. (Insert it to the inverter option connector 1.)
- (3) Fit the one location on the left of the earth plate (as shown in the next page) securely to the inverter unit by screwing in the supplied mounting screw. (tightening torque 0.33 N·m to 0.40 N·m)
- (4) Fit the one location on the left of the plug-in option securely to the inverter unit and the right of the plug-in option to the inverter unit together with the earth plate by screwing in the supplied mounting screws. (tightening torque 0.33 N·m to 0.40 N·m) If the screw holes do not line up, the connector may not be inserted deep enough. Check the connector.



Do not insert the plug-in option to the connector 2 or 3.



Insertion positions for screws and spacers

[Connection cable of the FR-A8NC]

In the CC-Link system, use CC-Link dedicated cables.

If the cable used is other than the CC-Link dedicated cable, the performance of the CC-Link system is not guaranteed.

For the specifications of the CC-Link dedicated cable, refer to the website of the CC-Link Partner Association.


- Website of the CC-Link Partner Association <http://www.cc-link.org/>
- One-touch communication connector plug (as of July 2013)

Refer to the following table for the plug required to fabricate a cable on your own.

Model	Manufacturer
A6CON-L5P	Mitsubishi Electric Corporation
35505-6000-B0M GF	Sumitomo 3M Limited

(1) Cable-end treatment

Apply the following treatment to the CC-Link dedicated cable that is inserted to a one-touch communication connector plug.




NOTE

- Where possible, round the cable tip that is cut off with a tool such as nippers. If the cable is not rounded, it may get caught in the middle of a plug, without fully entering into the plug.
- If required, apply an insulation treatment to the shielding wire area where it is not covered by the one-touch communication connector plug.

(2) Plug cover check

Check that a plug cover is snapped into a plug




NOTE

- Do not push the plug cover onto the plug before inserting a cable. Once crimped, the plug cover cannot be reused.

(3) Cable insertion

Lift up the tail of the plug cover, and fully insert a cable. Insert different signal wires to the one-touch communication connector plug as shown in the right figure.




NOTE

- Insert the cable fully. Failure to do so may cause a crimping failure.
- A cable sometimes comes out of the head of the cover. In that case, pull the cable a little so that the cable stays under the plug cover.

(4) Crimping the plug cover


Push the plug cover onto the plug with a tool such as pliers. After crimping, check that the plug cover is securely snapped into the plug as shown in the right figure.



NOTE

- Misaligned latches between the plug cover and the plug may keep the cover lifted. The plug cover is not sufficiently crimped in this condition. Push the plug cover until it snaps into the plug.

Connect the CC-Link dedicated cable to the CC-Link communication connector.







NOTE

- When wiring cables to the inverter's RS-485 terminals while a plug-in option is mounted, take caution not to let the cables touch the circuit board of the option or of the inverter. Otherwise, electromagnetic noises may cause malfunctions.

[Setting of the terminating resistor selection switch of the FR-A8NC]

For the inverter (FR-A8NC) of the end station, configure the terminating resistor selection switch setting in advance.

The following table shows the specifications of the terminating resistor selection switch.

Setting	1	2	Description
	OFF	OFF	Without terminating resistor (initial setting)
	ON	OFF	Do not use.
	OFF	ON	130 Ω (resistance value with the CC-Link Ver. 1.00 dedicated high performance cable)
	ON	ON	110 Ω