

## TECHNICAL BULLETIN

[1/31]

[Issue No.] GOT-A-0123-A [Title] Utilizing the Project File of the GOT for iQ Monozukuri ANDON [Date of Issue] January 2018 (Ver. A: March 2022) [Relevant Models] iQ Monozukuri ANDON

Thank you for your continued support of Mitsubishi Electric Graphic Operation Terminal (GOT). This technical bulletin provides supplementary information for [Utilizing the project file of the GOT for iQ Monozukuri ANDON] in [iQ Monozukuri ANDON Startup Manual (SH-081687ENG)]. The following two methods will be covered in this bulletin.

- How to utilize the project file of the GOT for iQ Monozukuri ANDON as your project file
- How to utilize your project file as the project file of the GOT for iQ Monozukuri ANDON

#### **Contents**

<ol> <li>Pre</li> </ol>	ecautions	3
1.1	Before utilizing the project file of the GOT for iQ Monozukuri ANDON	
1.2	The project file of the GOT for iQ Monozukuri ANDON	
1.3	S/W version	
1.4	How to utilize the project file of the GOT for iQ Monozukuri ANDON	3
1.5	Restricted items in setting changes	
2. Adv	vanced Preparation	
2.1	Procedures for the project file of the GOT for iQ Monozukuri ANDON	
2.1	.1 GOT type settings	
	.2 Controller settings	
2.2		
2.2		
2.2		
2.2		
2.2	.4 GOT name	
2.2		
2.2		
2.2	.7 FTP Server function	11
3. Util	izing the Project File of the GOT for iQ Monozukuri ANDON	12
3.1	Utilizing the project file of the GOT for iQ Monozukuri ANDON as your project file	12
3.1	.1 Confirming the functions to be utilized from the project file of the GOT	
	for iQ Monozukuri ANDON as your project file	12
3.1	<b>5</b> , , , , , , , , , , , , , , , , , , ,	
	(when utilizing the project file of the GOT for iQ Monozukuri ANDON)	15
3.2	Utilizing your project file as the project file of the GOT for iQ Monozukuri ANDON	23
3.2	.1 Confirming the functions to be utilized from your project file as the project file of the GOT	
	for iQ Monozukuri ANDON	23

## **TECHNICAL BULLETIN**

# [Issue No.] GOT-A-0123-A

3.2.2 Setting the functions which are required for the iQ Monozukuri ANDON sy	rstem
(when utilizing your project file)	20
3.3 Saving the project	
3.3.1 Transferring data to the GOT	2
3.3.2 Confirming the utilization settings	
3.3.3 Saving the project	
4. Settings Check List for iQ Monozukuri ANDON	
REVISIONS	
Intellectual Property Rights	

#### 1. Precautions

Confirm the below precautions before you start the procedures.

## 1.1 Before utilizing the project file of the GOT for iQ Monozukuri ANDON

When you utilize the project file of the GOT for iQ Monozukuri ANDON, some changes will be made to the settings of your project file.

Back up your project file before utilizing any other project file of the GOT for iQ Monozukuri ANDON.

#### 1.2 The project file of the GOT for iQ Monozukuri ANDON

Refer to the below manual and make sure to read it through in advance.

Manual name	Manual number		
iQ Monozukuri ANDON Startup Manual	SH-081687ENG		

#### 1.3 S/W version

Perform this procedure in the below S/W version.

S/W name	Version		
GT Designer3(GOT2000)	1.175H or later		

Before utilizing any project files, execute iQM\_ANDON\_Signage.exe which is included in the DVD. If you have ever executed the exe file before, there is no need to repeat this.

#### 1.4 How to utilize the project file of the GOT for iQ Monozukuri ANDON

This procedure uses [Utilize Project] of GT Designer3 (GOT2000).

For details of [Utilize Project], refer to the below manual.

Manual name	Manual number			
GT Designer3(GOT2000) Screen Design Manual	SH-081220ENG			

## 1.5 Restricted items in setting changes

Do not make any changes to the following settings of the project file of the GOT for iQ Monozukuri ANDON.

Changes to the below settings could result in incorrect operations of iQ Monozukuri ANDON.

Settings	Restricted items in setting changes	Details		
Project script	The script execution order	Do not change the execution order of the project scripts.		
Mobile screen	· The screen number for 30610 (Caution_common)	Do not change the screen numbers of the mobile screens		
Mobile Screen	· The screen number for 32767 (Splash)	30610 (Caution_common) and 32767 (Splash).		
Window screen	· The screen number for 30001 (Language setting)	Do not change the screen numbers of the window screens		
vvindow screen	· The screen number for 30002 (Clock setting)	30001 (Language setting) and 30002 (Clock setting).		

#### 2. Advanced Preparation

Before utilizing the project file of the GOT for iQ Monozukuri ANDON, confirm the settings in the project file of the GOT for iQ Monozukuri ANDON and your project file.

If the settings differ from the settings required for utilizing the project file of the GOT for iQ Monozukuri ANDON, change the settings.

#### 2.1 Procedures for the project file of the GOT for iQ Monozukuri ANDON


The below settings are required for the project file of the GOT for iQ Monozukuri ANDON.

## 2.1.1 GOT type settings

Set "GOT Type" according to the GOT in use.


If the GOT type is "GT27\*\*-V(640x480)", no change is necessary.

[Common]⇒[GOT Type Setting]




When you change the screen sizes, select "Perform Automatic Scaling on the positions/sizes of figures and objects". The screen size change is applied to the base screen.

(a) Select "Apply to Window Screen" under "Option" if you also want the window screen size to be changed.



## 2.1.2 Controller settings

Configure "Controller Setting" according to your controller's system configuration. [Common]⇒[Controller Setting]



## TECHNICAL BULLETIN


[Issue No.] GOT-A-0123-A


After configuring "Controller Setting", also change the below assignment (device) according to your system.

Comment	Target label name	Device in use			
Comment	rarget label flame	Before (Initial value)	After		
DANDORI start trigger	b_StrtDandori	M0			
DANDORI completion trigger	b_EndDandori	M1			
Production start trigger	b_StrtProduct	M2	Any controller device		
Production end trigger	b_EndProduct	M3	Any controller device		
Actual number	u32_AchvPrdct	D0			
Uptime status of the process 1 to16	s16_Event1 to s16_Event16	D10 to D25			

Save the project file after changing the labels.

"Project" ⇒ "Label " ⇒ "Label (GT Designer 3)" ⇒ "200 ADN\_System"





#### 2.2 Procedures for your project file

Confirm the settings in your project file.


If the settings are different from the below, change the settings in your project file.

#### 2.2.1 Internal device

Confirm that the internal devices listed below are not used.

Target		Details		
GOT internal device	· GD32000 to GD61279			
GOT internal device	· GB32000 to GB61279	The internal devices listed on the left are used for the ANDON		
GOT Mobile device	· VGD0 to VGD99	system in the project file of the GOT for iQ Monozukuri ANDON.		
GOT Mobile device	· VGB0 to VGB99	If you use any of these in your project file, change the settings in		
GOT special register*	GS385 (Script monitoring time)	your project file.		
Temporary device area	TMP800 to TMP1023			

## [Search/Replace] ⇒ [Batch Edit] ⇒ [Device]



## GOT special register GS385 (Script monitoring time)


iQ Monozukuri ANDON system uses GS385 (Script monitoring time) in the script.

If GS385 (Script monitoring time) is included in your project file, delete it.

When you change the settings in the script monitoring time, change "Device and Constant" of "u16\_SCRIPTCHECK" under "Script Symbol" dialog after utilizing the project file of the GOT for iQ Monozukuri ANDON.


## 2.2.2 Package folder name

Confirm if "Package Folder Name" is in 9 characters or less. [Common]⇒[GOT Type Setting]




When you change "Package Folder Name", also change "Device and Constant" in "str\_PACKAGEFOLDER" under the "Script Symbol" dialog.

[Common]⇒[Script]⇒[Script Symbol]




## 2.2.3 PC (Data Transfer) settings

Under the "PC (Data Transfer)" dialog, confirm that "Ethernet Download" is set to "Ethernet:Multi". [Common]⇒[Peripheral Setting]⇒[PC(Data Transfer)]



#### 2.2.4 GOT name

Confirm that you entered the desired name in "GOT Name". [Common]⇒[GOT Setup]⇒[Basic Setting]⇒[GOT ID No.]




#### 2.2.5 Local time in the time setting

Confirm that "Specify time zone" is selected.


(a) Set "Time Zone" arbitrarily based on your local time.

[Common]⇒[GOT Setup]⇒[Basic Setting]⇒[Time Setting]⇒[Local Time] tab



#### 2.2.6 SoftGOT-GOT link function

Confirm that "SoftGOT-GOT Link Function" is selected. [Common]⇒[Application Selection]⇒[System Application] tab




#### 2.2.7 FTP Server function

Confirm that "Use the function of FTP Server" is selected.

(a) Enter your desired "Login Name" and "Password".

[Common]⇒[Controller Setting]⇒ "Network/Duplex Setting"⇒"Gateway"⇒"FTP Server"



## 3. Utilizing the Project File of the GOT for iQ Monozukuri ANDON

To utilize the project file of the GOT for iQ Monozukuri ANDON, go to [Utilize Project] in GT Designer3(GOT2000). Find the below two methods of utilizing data from other projects.

- Utilizing the project file of the GOT for iQ Monozukuri ANDON as your project file
  - → Refer to 3.1.
- Utilizing your project file as the project file of the GOT for iQ Monozukuri ANDON
  - → Refer to 3.2.

## 3.1 Utilizing the project file of the GOT for iQ Monozukuri ANDON as your project file

# 3.1.1 Confirming the functions to be utilized from the project file of the GOT for iQ Monozukuri ANDON as your project file

(a): Select -: Deselect

□: Deselect when they are used in your project file (select when they are not used)

Select/ Deselect	Item	Functions used in the project file for iQ Monozukuri	
		ANDON	
0	Select screen-related settings as well	-	
0	Project Name	-	
_	GOT Environmental Setting/GOT Setup/GOT Ethernet Setting	-	
-*4	GOT Environmental Setting/GOT Setup/GOT Ethernet	GOT Name	
	Setting	Local Time	
		GOT Ethernet Setting	
_	CSP+ for iQSS Data Write	-	
_	Operation Log	-	
_	Controller Setting	-	
-	Network/Duplex Setting	-	
-	Routing Information	-	
_	Gateway	-	
_	Gateway Server	-	
_	Gateway Client	-	
_	Mail	-	
□*1	FTP Server	FTP Server	
_	File Transfer	-	
_	MELSEC Redundant	-	
_	Station No. Switching	-	
_	Buffer Memory Unit No. Switching	-	
-	Peripheral Setting	-	
-	Bar Code	-	
-	RFID	-	
-	VNC Server	-	
-	Video/RGB Input	-	
-	Multimedia	-	

## **TECHNICAL BULLETIN**

[Issue No.] GOT-A-0123-A


Deselect  *1 *3 -  ◎	External I/O/ Operation Panel GOT Network Interaction GOT Mobile Setting I/F Communication Setting Base Screen Base screens configured in the project Window screen Window screens configured in the project Report Screen Report Setting Mobile screen Mobile screens configured in the project Label Labels configured in the project Comment Alarm Alarm Alarm Common Setting User Alarm Observation	file for iQ Monozukur ANDON  - GOT Mobile - Template screens for the servers (GOT) - Template screens for the servers (GOT) - Template screens for the servers (GOT) - GOT labels Comments
-	GOT Network Interaction GOT Mobile Setting  I/F Communication Setting  Base Screen  Base screens configured in the project  Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	- GOT Mobile Template screens for the servers (GOT) - Template screens for the servers (GOT) - Template screens for the servers (GOT) GOT labels
-	GOT Network Interaction GOT Mobile Setting  I/F Communication Setting  Base Screen  Base screens configured in the project  Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	- Template screens for the servers (GOT) - Template screens for the servers (GOT) Template screens for the servers (GOT) GOT labels
-	GOT Mobile Setting  I/F Communication Setting  Base Screen  Base screens configured in the project  Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	- Template screens for the servers (GOT) - Template screens for the servers (GOT) Template screens for the servers (GOT) GOT labels
-	I/F Communication Setting  Base Screen  Base screens configured in the project  Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	- Template screens for the servers (GOT) - Template screens for the servers (GOT) Template screens for the servers (GOT) GOT labels
©*2  © *2  © 0  ©*2  © *2  © *2  © - © 0  = *1  = *1  0  © 0  © 0	I/F Communication Setting  Base Screen  Base screens configured in the project  Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	servers (GOT)  - Template screens for the servers (GOT)  Template screens for the clients (controllers)  - GOT labels
©*2  © *2  © 0 0*2  © *2 0 0*2 0 - 0 0*2 - 0 1 - 1 0 0 0 0 0 0	Base Screen  Base screens configured in the project  Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	servers (GOT)  - Template screens for the servers (GOT)  Template screens for the clients (controllers)  - GOT labels
©*2  © *2  © 0 0*2  © *2 0 0*2 0 - 0 0*2 - 0 1 - 1 0 0 0 0 0 0	Base screens configured in the project  Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	servers (GOT)  - Template screens for the servers (GOT)  Template screens for the clients (controllers)  - GOT labels
© *2 -	Window screen  Window screens configured in the project  Report Screen  Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm  Alarm Common Setting	servers (GOT)  - Template screens for the servers (GOT)  Template screens for the clients (controllers)  - GOT labels
©*2 © ©*2  © 0*2  ©*2  © © 0*2	Window screens configured in the project  Report Screen Report Setting Mobile screen Mobile screens configured in the project  Label Labels configured in the project  Comment Alarm Alarm Common Setting	- Template screens for the servers (GOT) Template screens for the clients (controllers) - GOT labels
©*2 © 0*2  ©*2  ©*2  ©*2  © - © 0*2	Report Screen Report Setting Mobile screen Mobile screens configured in the project  Label Labels configured in the project  Comment Alarm Alarm Common Setting	servers (GOT)  Template screens for the clients (controllers) - GOT labels
©*2  © *2  © *2  © *2  © *2  © *3  - *1  - *1	Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	- Template screens for the clients (controllers) - GOT labels
©*2  © *2  © *2  © *2  © *2  © *3  - *1  - *1	Report Setting  Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	clients (controllers) - GOT labels
©*2  © *2  © *2  © *2  © *2  © *3  - *1  - *1	Mobile screen  Mobile screens configured in the project  Label  Labels configured in the project  Comment  Alarm  Alarm Common Setting	clients (controllers) - GOT labels
©*2  © *2  © *2  © *2  © *2  © *3  - *1  - *1	Mobile screens configured in the project  Label Labels configured in the project  Comment  Alarm  Alarm Common Setting	clients (controllers) - GOT labels
©*2  ©*2  ©  -  ©  ©*2  -  0  0*2  -  1  -  1  -  -  -  0  0  0  0  0  0  0	Labels configured in the project  Comment  Alarm  Alarm Common Setting	
©*2 © - © 0 ©*2 □*1 - - - - ©	Comment Alarm Alarm Common Setting	
© -	Alarm Alarm Common Setting	Comments
-  ©  0*2  □*1  □*1  -  -  -  0  ©	Alarm Common Setting	-
©*2  □*1  □*1  -  -  -  -  ©  ©		-
©*2  □*1  □*1  -  -  -  -  -  ©	User Alarm Observation	_
-*1		_
-*1 - - - - - ©	User alarm observation configured in the project	Alarms and events
- - - - ©	System Alarm Observation	System Alarm Observation
0	Alarm Popup Display	Alarm Popup Display
0	Recipe	-
0	Recipe Common Setting	-
0	Recipe	-
0	Recipes configured in the project	-
0	Script	-
	Script (Project, Symbol)	Script Symbol
⊚*2	Scripts configured in the project	Scripts
□*1 *3	Trigger Action (Project)	Trigger Action
-	Time Action	-
_	Hard Copy	
©	Parts	
<u> </u>		Parts used in the template
-	Parts Setting	Parts used in the template screens for the servers (GOT)
©*2	Parts configured in the project	Parts used in the template screens for the servers (GOT)
-		(601)

<sup>\*1</sup> The settings in the project file of the GOT for iQ Monozukuri ANDON will overwrite the settings in your project file.

- \*2 These are used in the project file of the GOT for iQ Monozukuri ANDON.

  If they are also used in your project file, change the ID and/or No. in the settings of the project file of the GOT for iQ Monozukuri ANDON.
  - When you change these settings, select "Assign the first No." or "Detail Setting" in "Destination" under the "Utilize Project" dialog to utilize the project.
- \*3 When these are used in your project file, refer to [3.1.2 Setting the functions which are required for the iQ Monozukuri ANDON system (when utilizing the project file of the GOT for iQ Monozukuri ANDON)] and change the settings accordingly.
- \*4 Refer to [3.1.2 Setting the functions which are required for the iQ Monozukuri ANDON system (when utilizing the project file of the GOT for iQ Monozukuri ANDON)] and make the necessary changes or additions to the settings.

#### [Project]⇒[Utilize Project]



# 3.1.2 Setting the functions which are required for the iQ Monozukuri ANDON system (when utilizing the project file of the GOT for iQ Monozukuri ANDON)

When you use the below functions in your project file, change the settings after the [Utilize Project] procedure.

## (1) Trigger Action


Confirm the "Trigger Action" dialog.

Change the settings if the settings are different from the details below.

## : Select

No.	Condition		Action						
	Condition 1/	Settings	Action	Storing I	Storing Device Indirect		Device		fixed
	Condition 2								
	Trigger type	Trigger device		Points	Data		Device	Indirect	
1	Rise	\$ADN_System:b_StrtProduct	Bit set	1	_		Device: 0	Device: GB45040	
2	Rise	\$ADN_System:b_StrtDandori	Bit set	1	_		Device: GB45042		_
3	Rise	\$ADN_System:b_EndProduct	Bit set	1	_		Device: GB45041		_
4	Rise	\$ADN_System:b_EndDandori	Bit set	1	_		Device: GB45043		_
5	Rise	\$ADN_System:b_EntAchvPrdct	Data set	1	Unsigned	0	Device:		1
	ON	GB49985	(32 bits)		BIN32		\$ADN_S	ystem:u32_CntAc	
							hvPrdct		
							Indirect:		
							\$ADN_S	ystem:u32_CntAc	
							hvPrdct		
6	ON Sampling	\$ADN_System:b_InOperation	Data set	1	Unsigned	0	Device:		1
		1 second	(32 bits)		BIN32		\$ADN_S	ystem:u32_Actual	
	ON	\$ADN_System:b_StrtProduct					UpTimeC	Count	
							Indirect:		
							\$ADN_S	ystem:u32_Actual	
							UpTimeC	Count	
7	Rise	\$ADN_System:b_ActualUpTim	Data set	1	Unsigned	_	Device:		0
		eReset	(32 bits)		BIN32		\$ADN_S	ystem:u32_Actual	
							UpTimeC	Count	
8	OFF	\$ADN_System:b_InOperation	Data set	1	Unsigned	0	Device:		1
	Sampling	1 second	(32 bits)		BIN32		\$ADN_S	ystem:u32_Actual	
	ON	\$ADN_System:b_StrtProduct					DownTin	neCount	
							Indirect:		
							\$ADN_S	ystem:u32_Actual	
							DownTin	neCount	
9	Rise	\$ADN_System:b_ActualDownT	Data set	1	Unsigned	_	Device:		0
		imeReset	(32 bits)		BIN32		\$ADN_S	ystem:u32_Actual	
							DownTin	neCount	

## [Common]⇒[Trigger Action]



#### (2) GOT Mobile Setting


Confirm the "GOT Mobile Setting" dialog.

Change the settings if the settings are different from the below details.


[Common]⇒[GOT Mobile Setting]

#### Checklist


(a) "Allow external access to GOT public folder" under "Basic Setting" is selected.




(b) "Word Device" and "Bit Device" under "Device Allocation Setting" is set to "GD60000" and "GB60000" respectively.




(c) "Screen Switching Device" is set to "VGD0", and "BIN" is selected as "Screen Switching Device Data Type" under "Screen Switching".




(d) "Language Switching Device" under "Language Switching" is set to "VGD21".



(e) "Client No. Notification Device" and "Client IP Address Notification Device" under "Client Information" are set to "VGD22" and "VGD23" respectively.



(f) One of the boxes of No.1 to No.5 in "Target Client No." is selected under "ANDON Setting".




#### (3) System Information

After the [Utilize Project] procedure, change the system information based on your system.

When the system information is not used, refer to the setting details of iQ Monozukuri ANDON and configure the settings accordingly.

(Example) For setting the 13-bit (GOT Error Reset signal) to the bit device that is used in the [OK] switch in the window screen 30000 (GOT system alarm reset)




## (4) Change the Remote Control Settings

When you change the screen numbers of the mobile screens, it will affect the operation of the remote control screen.

When the below screen numbers are changed, utilize the data in [Utilize Project] and change the settings of the following switches in mobile screen 30080 (Remote control\_remote): "Uptime Status", "Production status (overall)", "Production status (progress)", and "Production status (simple)".

Screen Number	Screen Name	Title
30300	Uptime status1_andon	Uptime Status
30310	Prod. status (overall)_andon	Production status (overall)
30320	Prod. status (progress)_andon	Production status (progress)
30330	Prod. status (simple)_andon	Production status (simple)

(Example) For changing the screen number of mobile screen 30300 (Uptime status1\_andon) to "30400"



#### (5) Language Switching/Dialog Window

After the [Utilize Project] procedure, change the settings of "Language Switching" and "Dialog Window" based on your system.

When these settings are not used, refer to the setting details of iQ Monozukuri ANDON and configure the settings accordingly.


#### Device setting

Item	Setting
(a) Language Switching Device	\$ADN_System:s16_HMILanguage
(b) Dialog Window Switching Device	\$ADN_System:u16_DialogWindow


#### GOT label setting

Label name	Device in use	
	Before (Initial value)	After
s16_HMlLanguage	GD30021	Device that has been set to your
u16_DialogWindow	GD30018	project file

#### (a) [Common]⇒[GOT Environmental Setting]⇒[Language Switching]



## (b) [Common]⇔[GOT Environmental Setting]⇒[Dialog Window]



## 3.2 Utilizing your project file as the project file of the GOT for iQ Monozukuri ANDON

# 3.2.1 Confirming the functions to be utilized from your project file as the project file of the GOT for iQ Monozukuri ANDON

Select all of the functions listed below when utilizing your project file.

## ⊚: Select -: Deselect

Select/	Item	Functions used in the project	
Deselect	item	file for iQ Monozukuri ANDON	
	Calcat agreen related acttings as well	lile for IQ Moriozakan ANDON	
<u> </u>	Select screen-related settings as well	-	
0	Project Name	-	
©	GOT Environmental Setting/GOT Setup/GOT Ethernet Setting	-	
⊚*1 *4	GOT Environmental Setting/GOT Setup/GOT Ethernet	GOT Name	
	Setting	Local Time	
		GOT Ethernet Setting	
0	CSP+ for iQSS Data Write	-	
0	Operation Log	-	
0	Controller Setting	-	
0	Network/Duplex Setting	-	
0	Routing Information	-	
<u> </u>	Gateway	-	
<u> </u>	Gateway Server	-	
<u> </u>	Gateway Client	-	
©	Mail	_	
⊚*1 *3	FTP Server	FTP Server	
<u> </u>	File Transfer	-	
<u> </u>	MELSEC Redundant	_	
<u> </u>	Station No. Switching	_	
<u> </u>	Buffer Memory Unit No. Switching	_	
<u> </u>	Peripheral Setting	_	
	Bar Code	-	
<u> </u>		-	
0	RFID	-	
0	VNC Server	-	
<u> </u>	Video/RGB Input	-	
0	Multimedia	-	
<u> </u>	External I/O Operation Panel	-	
<u> </u>	GOT Network Interaction	-	
⊚*1 *4	GOT Mobile Setting GOT Mobile		
0	I/F Communication Setting -		
0	Base Screen -		
<b>©</b> *2	Base screens configured in the project	Template screens for the servers (GOT)	
0	Window screen	-	
©*2	Window screens configured in the project	Template screens for the servers (GOT)	
©	Report Screen	-	
	Topot Colodii		

Select/	Item	Functions used in the project	
Deselect		file for iQ Monozukuri ANDON	
0	Report Setting	-	
0	Mobile screen	-	
©*2	Mobile screens configured in the project	Template screens for the	
		clients (controllers)	
0	Label	-	
©*2	Labels configured in the project	GOT labels	
©*2	Comment	Comments	
0	Alarm	-	
0	Alarm Common Setting	-	
0	User Alarm Observation	-	
⊚*2	User alarm observation configured in the project	Alarms and Events	
⊚*1 *3	System Alarm Observation	System Alarm Observation	
⊚*1 *3	Alarm Popup Display	Alarm Popup Display	
0	Recipe	-	
0	Recipe Common Setting	-	
0	Recipe	-	
0	Recipes configured in the project	-	
0	Script	-	
0	Script (Project, Symbol)	Script Symbol	
©*2	Scripts configured in the project	Scripts	
⊚*1 *4	Trigger Action (Project)	Trigger Action	
0	Time Action	-	
0	Hard Copy -		
0	Parts	-	
0	Parts Setting	Parts used in the template	
		screens for the servers (GOT)	
©*2	Parts configured in the project	Parts used in the template	
		screens for the servers (GOT)	
0	Sound Files	-	
0	Touch Key Sound Setting	-	

The settings in your project file will overwrite the settings in the project file of the GOT for iQ Monozukuri ANDON.

These are used in the project file of the GOT for iQ Monozukuri ANDON.

If they are also used in your project file, change the ID and/or No. of the settings in your project file.

When you change these settings, select "Assign the first No." or "Detail Setting" in "Destination" under the "Utilize Project" dialog to utilize the project.


<sup>\*</sup> If any changes affect your existing system (such as the ladder program in the controllers), modify your project file as required.

When these are used in your project file, refer to [3.2.2 Setting the functions which are required for the iQ Monozukuri ANDON

system (when utilizing your project file)] and change the settings accordingly.

Refer to [3.1.2 Setting the functions which are required for the iQ Monozukuri ANDON system (when utilizing the project file of the GOT for iQ Monozukuri ANDON)] and make necessary changes or additions to the settings.

## [Project]⇒[Utilize Project]



# 3.2.2 Setting the functions which are required for the iQ Monozukuri ANDON system (when utilizing your project file)

After the [Utilize Project] procedure, confirm the below settings.

Change the settings if the settings are different from the below details.


## (1) System Alarm Observation

Confirm that the below settings are selected.

[Common]⇒[Alarm]⇒[System Alarm Observation]

#### Checklist

- (a) "Use System Alarm" is selected.
- (b) "CPU Error", "GOT Error", and "Network Error" under "Target" are selected.



#### (2) Alarm Popup Display


Confirm the settings in the alarm popup display. [Common]⇒[Alarm]⇒[Alarm Popup Display]

[Common] > [Alanni] > [Alanni | Opup Display

#### Checklist

- (a) "Use Alarm Popup Display" is selected.
- (b) "Display Alarm" is set to "System Alarm".
- (c) "Touch Mode" is set to "Screen Switching".
- (d) "Destination Screen" is set to "Overlap Window1".
- (e) "Destination Screen" is set to "30000 GOT system alarm reset".

If, however, you have changed the screen numbers when utilizing the project file, set the changed screen number.




## 3.3 Saving the project

Save the project file that has been created in the procedures explained in Chapter 3.1 to 3.3. Carry out the below operation before saving the project file.

## 3.3.1 Transferring data to the GOT


Open the "Communicate with GOT" dialog. [Communication]⇒[Write to GOT]



If you have changed any settings, transfer the data to the GOT.

## 3.3.2 Confirming the utilization settings

Confirm that "Include projects for the function of Utilize Data" is selected. [Project]⇔[Project Information]



## 3.3.3 Saving the project

After the above settings are done, save the project.

## 4. Settings Check List for iQ Monozukuri ANDON

After utilizing the project file of the GOT for iQ Monozukuri ANDON, confirm that all items in the below checklist are OK.

Check item	Details:	Results	
Internal Device	The internal devices are set.	OK .	NG
Package Folder Name	The package folder is named as "G2PACKAGE¥Package1" (*For 1.000A).  The package folder name is in 9 characters or less (*For	OK .	NG
	, ,		
PC (Data Transfer)	1.001B or later).  "Ethernet:Multi" is selected.	OK .	NG
GOT Name	Your desired name is entered.	OK .	NG
Local Time in the Time Setting	"Specify time zone" is selected.	OK .	NG
Local fille in the fille Setting	The desired time zone is set.	OK .	NG
SoftGOT-GOT Link Function	"SoftGOT-GOT Link Function" is selected.	OK ·	NG
FTP Server Function	"Use the function of FTP Server" is selected.	OK ·	NG
FIF Server Function			NG
Trigger Action	Your desired "Login Name" and "Password" are entered.	OK •	
Trigger Action	The trigger actions are set.	OK •	NG
GOT Mobile Setting	(a) "Allow external access to GOT public folder" under "Basic Setting" is selected.	OK .	NG
	(b) "Word Device" and "Bit Device" under "Device Allocation Setting" is set to "GD60000" and "GB60000" respectively.	OK •	NG
	(c) "Screen Switching Device" is set to "VGD0", and "BIN" is selected as "Screen Switching Device Data Type" under "Screen Switching".	OK .	NG
	(d) "Language Switching Device" under "Language Switching" is set to "VGD21"	OK .	NG
	(e) "Client No. Notification Device" and "Client IP Address Notification Device" under "Client Information" are set to "VGD22" and "VGD23" respectively.	OK .	NG
	(f) One of the boxes of No.1 to No.5 in "Target Client No." is selected under "ANDON Setting".	OK .	NG
System Information	The system information is set.	OK .	NG
Remote Control Setting	The screen numbers and switches are set.	OK .	NG
Language Switching	(a) "Language Switching Device" is set.	OK .	NG
	(b) "Dialog Window Switching Device" is set.	OK .	NG
System Alarm Observation	(a) "Use System Alarm" is selected.	OK .	NG
	(b) "CPU Error", "GOT Error" and "Network Error" under "Target" are selected.	OK .	NG
Alarm Popup Display	(a) "Use Alarm Popup Display" is selected.	OK .	NG
	(b) "Display Alarm" is set to "System Alarm".	OK .	NG
	(c) "Touch Mode" is set to "Screen Switching".	OK .	NG
	(d) "Destination Screen" is set to "Overlap Window1".	OK .	NG
	(e) "Destination Screen" is set to "30000 GOT system alarm reset".	OK .	NG
Utilization Settings	"Include projects for the function of Utilize Data" is selected.	OK .	NG
		-···	

## **REVISIONS**

Version	Print Date	Revision
-	January 2018	- First edition
Α	March 2022	- Updated the version (compatible with e-Manual Viewer)

## **Intellectual Property Rights**

## ■Copyrights

The screens (screenshots) are used in accordance with the Microsoft Corporation guideline.