



L60DA4

**Digital-analog converter module**



**High-speed and smooth continuous analog outputs!**

**New! Industry First\*<sup>1</sup> wave output function!**

\*<sup>1</sup> As of April 2012, Mitsubishi Electric Corp. survey

**What is the wave output function?**

With this function, wave data for the target analog values to be output are registered in a digital-analog (D/A) converter module. The wave data with digital values are continuously output as analog at a preset conversion cycle.




\*<sup>2</sup> Supported by the modules whose first five serial number digits are 14041 or later.

**Using the wave output function**

Realize high-speed and smooth continuous analog output which does not rely on the sequence scan time.

**To output analog values with the sequence program control**

Analog output values at each scan time.




The actual analog output values are deviated from the target wave data.



**To output analog values with the wave output function**

Analog output values at a specific interval.



The target analog values are achieved!



# Point 1 Easy to use! Just create and store wave data!

## How to use the wave output function


Wave data can be created with easy mouse operation using the "Create Wave Output Data"\*1 tool in GX Works2. The created wave data are registered in a D/A converter module and can be output as smooth continuous analog values.

\*1 Supported with GX Works2 Ver. 1.87R or later.

### STEP 1 Using GX Works2, create wave data to be output as analog.



### STEP 2 Save the wave data in the CPU module's file register (or SD memory card), and execute a function block (FB)\*2.







# Point 2 Easily adjust wave output data!

Wave output data (digital value) on the D/A module buffer memory address can be adjusted even while the D/A module is running by using the wave output step action function. This function is perfect for confirming analog output values and for adjusting the created wave output data.

**Wave output step action function** **New!**

### To output the designated buffer memory address values as analog

Example: Wave output step action in the "-10 to 10V" output range while the wave output is running.



## Function List

Item	Description
D/A conversion enable/disable function	This function sets whether to enable or disable D/A conversion for each channel. Disabling the D/A conversion for unused channels reduces the conversion cycles.
D/A output enable/disable function	This function sets whether to output the D/A conversion value or the offset value for each channel. The conversion speed is constant, regardless of the output enable/disable status.
Range switching function	The output range to use can be selected from the factory default range (4 to 20mA, 0 to 20mA, 1 to 5V, 0 to 5V, or -10 to 10V) and user range (user range setting).
Offset/gain setting function	This function compensates for errors in analog output values.
Analog output HOLD/CLEAR function	This function sets whether to hold the output analog value (HOLD) or clear the output analog value (CLEAR), according to the CPU module operating status (RUN, STOP, or stop error).
Analog output test when CPU module is in STOP status	When the CPU module is in STOP operation status, forcibly turning CH0 Output enable/disable flag (Y1 to Y4) ON outputs the D/A-converted analog value.
Scaling function	This function scales a digital value into a value within the range of the set scaling lower limit value to scaling upper limit value. The programming for scale conversion can be omitted.
Warning output function	This function outputs a warning when the digital value enters the preset warning output range.
Wave output function <b>NEW</b>	This function imports the prepared wave data (digital value) and outputs the data (analog value) in the set conversion cycle. A faster and smoother control than a program control is achieved by the automatic output of the control wave data registered in the D/A converter module for the analog (torque) control such as pressing machines and injection molding machines. The control can be executed only by registering the wave data to the D/A converter module. Therefore, the program-less control is available for the repeat control such as the line control, and man-hours for programming can be reduced.
Wave output step action function <b>NEW</b>	This function changes addresses and data values to be output to change the analog output flexibly at any timing in the wave output mode. This function is useful for the analog output test in the wave output mode and for debugging the wave output function.
External power supply READY flag (X7)	This signal turns ON when the external power supply 24VDC is supplied. When the flag is OFF, 0V/0mA are output to analog output values regardless of other settings.
Error log function	This function stores up to 16 errors and alarms that occur on the D/A converter module to the buffer memory as history.
Module error collection function	This function collects the errors and alarms caused in the D/A converter module into the CPU module.
Error clear function	Clearing the error from the system monitor at error occurrence is possible.
Save/restoration of offset/gain value	The offset/gain value of the user range setting can be saved or restored.

## Performance Specifications

Item	Specifications					
Number of analog output points	4 points (4 channels)					
Digital input	-20480 to 20479					
When using the scaling function	-32768 to 32767					
Analog output	-10 to 10 VDC (external load resistance 1kΩ to 1MΩ)					
Current	0 to 20 mADC (external load resistance 0Ω to 600Ω)					
I/O characteristics, resolution*1	Analog output range		Digital value		Resolution	
	Voltage	0 to 5V	0 to 20000	-20000 to 20000	250μV	
		1 to 5V			200μV	
		-10 to 10V			500μV	
		User range setting			333μV*2	
	Current	0 to 20mA	0 to 20000	-20000 to 20000	1000nA	
4 to 20mA		800nA				
User range setting		700nA*2				
Accuracy (accuracy for the maximum value of analog output value)*3	Ambient temperature 25±5°C	Within ±0.1% (voltage: ±10mV, current: ±20μA)				
	Ambient temperature 0 to 55°C	Within ±0.3% (voltage: ±30mV, current: ±60μA)				
Conversion speed	Normal output mode	20μs/channel				
	Wave output mode	50μs/channel 80μs/channel				
Number of offset/gain settings	Up to 50000 counts					
Output short protection	Protected					
Insulation method	Between I/O terminals and programmable controller power supply: photocoupler isolation Between output channels: no insulation Between external power supply and analog output: transformer insulation					
Dielectric withstand voltage	Between I/O terminals and programmable controller power supply: 500VACrms for 1 minute Between external power supply and analog output: 500VACrms for 1 minute					
Insulation resistance	Between I/O terminals and programmable controller power supply: 500VDC 10MΩ or higher					
Number of occupied I/O points	16 points (I/O assignment: Intelligent 16 points)					
Connected terminal	18-point terminal block					
Applicable wire size	0.3 to 0.75mm <sup>2</sup>					
Applicable solderless terminal	R1.25 to 3 (solderless terminals with sleeve are not usable)					
External power supply	24VDC +20%, -15%					
	Ripple, spike 500mVp-p or lower					
	Inrush current: 4.3A, 1000μs or shorter					
	Current consumption: 0.18A					
Internal current consumption (5VDC)	0.16A					
Weight	0.20kg					


\*1: For details on the I/O conversion characteristics, refer to "Appendix 3, I/O conversion characteristic of D/A conversion" in the manual.

\*2: Maximum resolution in the user range setting.

\*3: Except when receiving noise influence. Warm up (power on) the module for 30 minutes to satisfy the accuracy shown in the table.

# External Dimensions

L60DA4




Unit: mm

## Product List

Product name	Model
MELSEC-L series digital-analog converter module	L60DA4

\* SD memory card is a trademark of Panasonic Corporation, SanDisk Corporation and Toshiba Corporation.  
 \* The SD logo is a trademark of SD-3C and LLC.

Mitsubishi Electric Corporation Nagoya Works is a factory certified for ISO14001 (standards for environmental management systems) and ISO9001 (standards for quality assurance management systems)



Country/Region	Sales office	Tel/Fax	Country/Region	Sales office	Tel/Fax
USA	Mitsubishi Electric Automation Inc. 500 Corporate Woods Parkway, Vernon Hills, IL 60061, USA	Tel : +1-847-478-2100 Fax: +1-847-478-2253	South Africa	CBI-Electric. Private Bag 2016, ZA-1600 Isando, South Africa	Tel : +27-11-977-0770 Fax: +27-11-977-0761
Brazil	MELCO-TEC Representacao Comercial e Assessoria Tecnica Ltda. Av Paulista, 1439, cj74, Bela Vista, Sao Paulo CEP: 01311-200-SP Brazil	Tel : +55-11-3146-2200 Fax: +55-11-3146-2217	China	Mitsubishi Electric Automaiton (China) Ltd. 10F, Mitsubishi Electric Automation Center, No.1386 Hongqiao Road, Changning District, Shanghai, China	Tel : +86-21-2322-3030 Fax: +86-21-2322-3000
Germany	Mitsubishi Electric Europe B.V. German Branch Gothaer Strasse 8, D-40880 Ratingen, Germany	Tel : +49-2102-486-0 Fax: +49-2102-486-1120	Taiwan	Setsuyo Enterprise Co., Ltd. 6F., No.105, Wugong 3rd Road, Wugu District, New Taipei City 24889, Taiwan, R.O.C.	Tel : +886-2-2299-2499 Fax: +886-2-2299-2509
UK	Mitsubishi Electric Europe B.V. UK Branch Travellers Lane, Hatfield, Hertfordshire, AL10 8XB, UK	Tel : +44-1707-27-6100 Fax: +44-1707-27-8695	Korea	Mitsubishi Electric Automation Korea Co., Ltd. 3F, 1480-6, Gayang-Dong, Gangseo-Gu Seoul 157-200, Korea	Tel : +82-2-3660-9530 Fax: +82-2-3664-8372
Italy	Mitsubishi Electric Europe B.V. Italian Branch Viale Colleoni 7-20864 Agrate Brianza (Milano), Italy	Tel : +39-039-60531 Fax: +39-039-6053-312	Singapore	Mitsubishi Electric Asia Pte, Ltd. Industrial Division 307, Alexandra Road, Mitsubishi Electric Building, Singapore, 159943	Tel : +65-6470-2308 Fax: +65-6476-7439
Spain	Mitsubishi Electric Europe B.V. Spanish Branch Carretera de Rubi 76-80. AC.420, E-08190 Sant Cugat del Valles (Barcelona), Spain	Tel : +34-93-565-3131 Fax: +34-93-589-2948	Thailand	Mitsubishi Electric Automation (Thailand) Co., Ltd. Bang-Chan Industrial Estate No.111 Soi Serithai 54, T.Kannayao, A.Kannayao, Bangkok 10230 Thailand	Tel : +66-2906-3238 Fax: +66-2906-3239
France	Mitsubishi Electric Europe B.V. French Branch 25,Boulevard des Bouvets, F-92741 Nanterre Cedex, France	Tel : +33-1-5568-5568 Fax: +33-1-5568-5757	Indonesia	P.T. Autoteknindo Sumber Makmur Muara Karang Selatan, Block A/Utara No.1 Kav. No.11, Kawasan Industri Pergudangan, Jakarta-Utara 14440, P.O. Box 5045, Indonesia	Tel : +62-21-663-0833 Fax: +62-21-663-0832
Czech Republic	Mitsubishi Electric Europe B.V.-o.s.Czech office Avenir Business Park, Radicka 751/113e, 158 00 Praha 5, Czech Republic	Tel : +420-251-551-470 Fax: +420-251-551-471	India	Mitsubishi Electric India Pvt. Ltd. 2nd Floor, Tower A & B, Cyber Greens, DLF Cyber City, DFL Phase III, Gurgaon-122002 Haryana, India	Tel : +91-124-463-0300 Fax: +91-124-463-0399
Poland	Mitsubishi Electric Europe B.V. Polish Branch ul.Krakowska 50, 32-083 Balice, Poland	Tel : +48-12-630-47-00 Fax: +48-12-630-47-01	Australia	Mitsubishi Electric Australia Pty.Ltd. 348 Victoria Road PO BOX11, Rydalmere, N.S.W 2116, Australia	Tel : +61-2-9684-7777 Fax: +61-2-9684-7245
Russia	Mitsubishi Electric Europe B.V. Russian Branch St.Petersburg office Piskarevsky pr. 2, bld 2, lit "Sch", BC "Benua", office 720; 195027, St.Petersburg, Russia	Tel : +7-812-633-3497 Fax: +7-812-633-3499			

## MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE: TOKYO BUILDING, 2-7-3, MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN  
 NAGOYA WORKS: 1-14, YADA-MINAMI 5, HIGASHI-KU, NAGOYA, JAPAN

1208 (MDOC)

Specifications subject to change without notice.  
 Printed in Japan on recycled paper.