

## 三菱扇風機 形名順 販売年度一覽表

形名	販売開始年	経過年数	形名	販売開始年	経過年数	形名	販売開始年	経過年数
A30-IV	1981	26	CF30B14B	1981	26	CF30T16B	1983	24
C-130B	1950	57	CF30B3BL	1972	35	CF30T16G	1983	24
C-140A	1956	51	CF30B3LB	1972	35	CF30T16P	1983	24
C-140B	1960	47	CF30B5BL	1973	34	CF30T17B	1984	23
C-140BC	1964	43	CF30B5LB	1973	34	CF30T17G	1984	23
C140-BD	1972	35	CF30B5LG	1973	34	CF30T17S	1984	23
C140-BD2	1976	31	CF30B6BL	1974	33	CF30T18B	1985	22
C140-BD3	1977	30	CF30B6LG	1974	33	CF30T18PI	1985	22
C140-BD5	1978	29	CF30B7BL	1975	32	CF30T19B	1986	21
C140-BD5-1	1979	28	CF30B7LG	1975	32	CF30T19PI	1986	21
C140-BE	1981	26	CF30B8BL	1976	31	CF30T5BL	1973	34
C140-NB	1996	11	CF30B8LG	1976	31	CF30T5LB	1973	34
C140-NB2	1997	10	CF30K10BL	1977	30	CF30T5LG	1973	34
C140-VB	2000	7	CF30K10GR	1977	30	CF30T6BL	1974	33
C140-VB-BK	2000	7	CF30K10LG	1977	30	CF30T6LG	1974	33
C140-WB	2005	2	CF30K11BK	1978	29	CF30T7BL	1975	32
C140-WB-BK	2005	2	CF30K11BL	1978	29	CF30T7LG	1975	32
C-26A	1954	53	CF30K11GR	1978	29	CF30T8BL	1976	31
C-36B	1950	57	CF30K12BK	1979	28	CF30T8LG	1976	31
C-36C	1957	50	CF30K12BL	1979	28	CY-023	1989	18
C-52B	1949	58	CF30K12GR	1979	28	CY-024	1989	18
C-56A	1957	50	CF30K13A	1980	27	CY-123	1996	11
C-90B	1956	51	CF30K13B	1980	27	CY-124	1996	11
C-90C	1961	46	CF30K13G	1980	27	CY-16A	1955	52
C-90CC	1964	43	CF30K14B	1981	26	CY-16B	1957	50
C90-CD	1972	35	CF30K14G	1981	26	CY-16C	1958	49
C90-CD2	1976	31	CF30K14P	1981	26	CY-22	1999	8
C90-CD3	1977	30	CF30K15B	1982	25	CY-301	2006	1
C90-CD5	1978	29	CF30K15G	1982	25	CY-302	2006	1
C90-CD5-1	1979	28	CF30K15P	1982	25	CY-30A	1959	48
C90-CE	1981	26	CF30K16B	1983	24	CY-30AB	1961	46
C90-NC	1996	11	CF30K16G	1983	24	CY-30AE	1962	45
C90-NC2	1997	10	CF30K16P	1983	24	CY-30AF	1963	44
C90-VC	2000	7	CF30K17B	1984	23	CY-30B	1964	43
C90-VC-BK	2000	7	CF30K17P	1984	23	CY-30C	1967	40
C90-WC	2005	2	CF30K17R	1984	23	CY-30C2	1970	37
C90-WC-BK	2005	2	CF30K6BL	1974	33	CY30-C3	1972	35
CA-12S	1983	24	CF30K6LG	1974	33	CY30-C5	1976	31
CF30A	1971	36	CF30K7BL	1975	32	CY30-C6	1978	29
CF30A10BL	1977	30	CF30K7LG	1975	32	CY30-C6B	1980	27
CF30A10GR	1977	30	CF30K8BL	1976	31	CY30-C6C	1980	27
CF30A11B	1978	29	CF30K8LG	1976	31	CY30-C7	1982	25
CF30A11G	1978	29	CF30R10B	1977	30	CY30-C8	1986	21
CF30A12BL	1979	28	CF30R11B	1978	29	CY30-C9	1988	19
CF30A12GR	1979	28	CF30R12B	1979	28	CY30-D	1993	14
CF30A13B	1980	27	CF30R13B	1980	27	CY30-DN	1996	11
CF30A14B	1981	26	CF30R14B	1981	26	CY30-MD	1995	12
CF30A14G	1981	26	CF30R15B	1982	25	CY30-TD	1997	10
CF30A14P	1981	26	CF30R7BL	1975	32	CY30-TD2	1999	8
CF30A3BL	1971	36	CF30R8BL	1976	31	CY30-WD	2006	1
CF30A3LG	1971	36	CF30T10BL	1977	30	CY-401	2006	1
CF30A5BL	1973	34	CF30T10GR	1977	30	CY-402	2006	1
CF30A5LB	1973	34	CF30T11BK	1978	29	CY-40A	1955	52
CF30A5LG	1973	34	CF30T11BL	1978	29	CY-40B	1956	51
CF30A6BL	1974	33	CF30T11GR	1978	29	CY-40C	1958	49
CF30A7BL	1975	32	CF30T12BL	1979	28	CY-40D	1960	47
CF30A8BL	1975	32	CF30T12GR	1979	28	CY-40DC	1962	45
CF30B	1971	36	CF30T13BL	1980	27	CY-40DD	1963	44
CF30B10BL	1977	30	CF30T13GR	1980	27	CY-40E	1964	43
CF30B10GR	1977	30	CF30T14B	1981	26	CY-40F	1967	40
CF30B11BL	1978	29	CF30T14G	1981	26	CY-40F2	1970	37
CF30B11GR	1978	29	CF30T14P	1981	26	CY40-F3	1972	35
CF30B12BL	1979	28	CF30T15B	1982	25	CY40-F5	1976	31
CF30B12GR	1979	28	CF30T15G	1982	25	CY40-F6	1977	30
CF30B13G	1980	27	CF30T15P	1982	25	CY40-F6B	1980	27

## 三菱扇風機 形名順 販売年度一覽表

形名	販売開始年	経過年数	形名	販売開始年	経過年数	形名	販売開始年	経過年数
CY40-F6C	1980	27	D25-E9	1969	38	D30-JB	1973	34
CY40-F7	1982	25	D-25G	1961	46	D30-JC	1974	33
CY40-F8	1986	21	D-25H	1960	47	D30-JE	1975	32
CY40-F9	1988	19	D-25HB	1961	46	D30-JG	1976	31
CY40-G	1993	14	D305-J	1987	20	D30-JK	1977	30
CY40-GN	1996	11	D30A-G	1984	23	D30-JK2	1977	30
CY-40M	1959	48	D30A-J	1984	23	D30-JP	1978	29
CY40-MG	1995	12	D30A-L	1984	23	D30-JP2	1978	29
CY40-TG	1997	10	D30B-G	1985	22	D30-JS	1979	28
CY40-TG2	1999	8	D30B-J	1985	22	D30-JS2	1979	28
CY40-WG	2006	1	D30B-L	1985	22	D30-JS2A	1979	28
CY-50DC	1961	46	D30C-G	1986	21	D30-JSA	1979	28
D-10B	1952	55	D30C-J	1987	20	D30-JT	1981	26
D-10C	1955	52	D30C-L	1985	22	D30-JTB	1980	27
D-10D	1955	52	D30D-S	1987	20	D30-JTG	1980	27
D-10DB	1956	51	D30E-S	1988	19	D30-JTL	1980	27
D-12A	1950	57	D30-F	1963	44	D30-JV	1981	26
D-12B	1949	58	D30-F2	1964	43	D30-JX	1982	25
D-12C	1952	55	D30-F3	1965	42	D30-JY	1981	26
D-12D	1953	54	D30-F7	1966	41	D30-JZ	1983	24
D-12E	1954	53	D30-FB	1964	43	D30-JZ2	1984	23
D-12F	1955	52	D30-G	1963	44	D-30K	1961	46
D-12G	1956	51	D30-G2	1964	43	D30-K	1970	37
D-12GB	1956	51	D-30GB	1961	46	D30-LA	1972	35
D-12GD	1958	49	D-30GD	1959	48	D30-LB	1973	34
D-12H	1955	52	D30-GT	1975	32	D30-LB2	1973	34
D-12K	1956	51	D30-GT2	1976	31	D30-LC	1974	33
D-12KB	1956	51	D30-GT3	1977	30	D30-LC2	1974	33
D-12M	1958	49	D30-GT5	1978	29	D30-LE	1975	32
D-16B	1949	58	D30-GT5A	1978	29	D30-LE2	1976	31
D-16C	1953	54	D30-GTB	1980	27	D30-LE3A	1978	29
D-20A	1963	44	D30-GTB2	1976	31	D30-LG	1976	31
D20-A2	1964	43	D30-GTB3	1977	30	D30-LK	1977	30
D20-A5	1965	42	D30-GTG	1980	27	D30-LK2	1977	30
D20-A6	1967	40	D30-GTG3	1977	30	D30-LP	1978	29
D20-A7	1970	37	D30-GTG5	1978	29	D30-LP2	1978	29
D20-A8	1972	35	D30-GTG5A	1978	29	D30-LS	1978	29
D20-AB	1973	34	D30-GTG6	1979	28	D30-LS2	1979	28
D20-AC	1974	33	D30-GTV	1975	32	D30-LSA	1979	28
D20-AE	1975	32	D30-GTV2	1976	31	D30-LSA2	1979	28
D20-AG	1976	31	D30-GTV3	1977	30	D30-LT	1981	26
D20-AG2	1976	31	D30-GTV5	1978	29	D30-LTB	1980	27
D20-AG3	1977	30	D30-GTV5A	1978	29	D30-LTG	1980	27
D20-AG5	1977	30	D30-GTW6	1979	28	D30-LV	1981	26
D20-AS	1979	28	D30-GV	1981	26	D30-LX	1982	25
D20-AS2	1979	28	D30-GVG	1981	26	D30-LZ	1983	24
D20-AS2A	1979	28	D30-GX	1982	25	D-30M	1959	48
D20-ASA	1979	28	D30-H	1963	44	D-30N	1959	48
D20-AT	1981	26	D30-H10	1970	37	D-30NB	1959	48
D20-ATG	1980	27	D30-H11	1971	36	D-30NC	1960	47
D20-ATY	1980	27	D30-H12	1972	35	D-30NH	1961	46
D20-AV	1981	26	D30-H2	1964	43	D-30P	1959	48
D20-AZ	1983	24	D30-H5	1965	42	D30-P	1961	46
D-20E	1959	48	D30-H6	1966	41	D-30R	1960	47
D-20EB	1959	48	D30-H7	1968	39	D-30RE	1961	46
D-20F	1960	47	D30-H8	1969	38	D30-S	1971	36
D-20G	1961	46	D30-H9	1969	38	D-30X	1962	45
D-20H	1961	46	D30-HB	1973	34	D30-Z	1980	27
D-20J	1962	45	D30-HB2	1973	34	D30-ZV	1981	26
D22-AG2	1977	30	D30-HC	1974	33	D30-ZX	1982	25
D25C-A	1986	21	D30-HC2	1974	33	D35-L	1963	44
D-25DB	1959	48	D30-HC3	1975	32	D35-L2	1964	43
D-25DC	1958	49	D30-HE	1975	32	D35-L5	1965	42
D-25E	1963	44	D30-HG	1976	31	D-40C	1959	48
D25-E10	1970	37	D30-J2	1967	40	D40C-P	1985	22
D25-E2	1964	43	D30-J3	1968	39	D40D-P	1988	19
D25-E5	1965	42	D30-J5	1969	38	D40-P	1963	44
D25-E6	1966	41	D30-J6	1970	37	D40-P10	1970	37
D25-E7	1967	40	D30-J7	1971	36	D40-P11	1971	36
D25-E8	1968	39	D30-J8	1972	35	D40-P12	1972	35

## 三菱扇風機 形名順 販売年度一覽表

形名	販売開始年	経過年数
D40-P2	1964	43
D40-P5	1965	42
D40-P6	1966	41
D40-P7	1967	40
D40-P8	1968	39
D40-P9	1969	38
D40-PB	1973	34
D40-PC	1974	33
D40-PE	1975	32
D40-PG	1976	31
D40-PK	1977	30
D40-PP	1978	29
D40-PS	1979	28
D40-PT	1981	26
D40-PTB	1980	27
D40-PV	1981	26
D-8A	1950	57
D-8B	1950	57
D-8C	1953	54
D-8D	1955	52
DM-10E	1958	49
DM-12A	1955	52
DM-12C	1953	54
DM-12GB	1956	51
DM-12GC	1956	51
DM-12GD	1958	49
DM-12HC	1958	49
DM-12L	1958	49
DM-14A	1955	52
DM-14D	1958	49
DM-14GB	1957	50
DM-16C	1955	52
DM-16E	1958	49
DM-16GB	1957	50
DM-25DC	1958	49
DM-25DD	1958	49
DM-25E	1959	48
DM-25EC	1959	48
DM-25F	1959	48
DM-25G	1960	47
DM-25K	1961	46
DM-30A	1969	38
DM-30GD	1958	49
DM-30GE	1958	49
DM-30GG	1958	49
DM-30GK	1958	49
DM-30GL	1958	49
DM-30HC	1959	48
DM-30HD	1959	48
DM-30L	1959	48
DM-30LC	1959	48
DM-30LD	1958	49
DM-30N	1959	48
DM-30NB	1959	48
DM-30NC	1960	47
DM-30NE	1961	46
DM-30NJ	1961	46
DM-30V	1962	45
DM-30W	1962	45
DM-35A	1960	47
DM-35D	1959	48
DM-35DB	1958	49
DM-35DC	1959	48
DM-35DE	1958	49
DM-35DF	1960	47
DM-35DG	1961	46
DM-35E	1962	45
DM-35F	1962	45
DM-35G	1962	45
DM-35GB	1962	45

形名	販売開始年	経過年数
DM-40E	1959	48
DM-40EC	1959	48
DM-40ED	1958	49
DM-40EE	1958	49
DM-40EG	1958	49
DM-40EJ	1961	46
DM-40EL	1961	46
DM-40F	1962	45
DM-40FB	1962	45
DM-40G	1962	45
DM-40GB	1962	45
DM-40H	1962	45
F-300AZ BE	1991	16
F-300AZ GY	1991	16
F-300BZ B	1991	16
F-300BZ C	1991	16
F-300K B	1983	24
F-300K2 S	1984	23
F-300K5 B	1985	22
F-300K5 CP	1985	22
F-300K5 G	1985	22
F-300M B	1986	21
F-300M PI	1986	21
F-300M W	1986	21
F-300M2 B	1988	19
F-300M2 BE	1988	19
F-300M2 BK	1988	19
F-300M3 BK	1988	19
F-300M3 BU	1988	19
F-300M5 BU	1989	18
F-300M5 GR	1989	18
F-300M5 W	1989	18
F-300M6 BK	1990	17
F-300M6 BU	1990	17
F-300M6 IB	1990	17
F-300X1 B	1982	25
F-300X1 G	1982	25
F-300X2 B	1984	23
F-300X2 G	1984	23
F-30R B	1983	24
F-30R2 S	1984	23
F-A300L B	1987	20
F-A300L R	1987	20
F-A300L W	1987	20
F-A300L2 GR	1988	19
F-A300L2 W	1988	19
JC-24D	1995	12
JF-401	1996	11
JF-402	1996	11
K20-BT	1981	26
K20-BTG	1980	27
K20-BTP	1980	27
K20-BV	1981	26
K20-BZ	1984	23
K30A-C	1983	24
K30A-H	1983	24
K30A-R	1983	24
K30B-C	1985	22
K30B-R	1985	22
K30C-C	1986	21
K30C-R	1986	21
K30-CT	1981	26
K30-CTB	1980	27
K30-CTG	1980	27
K30-CV	1981	26
K30-CX	1982	25
K30-CZ	1983	24
K30D-C	1987	20
K30D-R	1987	20
K30E-C	1988	19

形名	販売開始年	経過年数
K30E-R	1988	19
K30F-Q	1989	18
K30F-R	1989	18
K30G-Q	1990	17
K30G-S	1990	17
K30H-Q	1991	16
K30H-S	1991	16
K30J-Q	1992	15
K30J-S	1992	15
K30-KQ	1993	14
K30-KS	1993	14
K30-LQ	1994	13
K30-MQ	1995	12
K30-MS	1995	12
K30-OX	1982	25
K30-Q	1967	40
K30-Q2	1968	39
K30-Q3	1969	38
K30-Q5	1970	37
K30-Q7	1971	36
K30-Q8	1972	35
K30-QB	1973	34
K30-QC	1974	33
K30-QE	1975	32
K30-QG	1976	31
K30-QK	1977	30
K30-QP	1978	29
K30-QS	1979	28
K30-QV	1981	26
K30-QX	1982	25
K30-R	1969	38
K30-R2	1970	37
K30-R3	1971	36
K30-R5	1972	35
K30-RB	1973	34
K30-RC	1974	33
K30-RE	1975	32
K30-RG	1976	31
K30-RK	1977	30
K30-RP	1978	29
K30-RS	1979	28
K30-RTL	1980	27
K30-RV	1981	26
K30-RX	1982	25
K30-SG	1977	30
K30-SG2	1978	29
K30-SG3	1979	28
K30-ST	1981	26
K30-STG	1980	27
K30-SV	1981	26
K30-TQ	1997	10
K30-TQ2	1999	8
K30-TQ4	2000	7
K30-TS	1997	10
K30-TS2	1998	9
K30-TS3	1999	8
K30-TS4	2000	7
K30-UQ	2001	6
K30-US	2001	6
K30-WQ	2002	5
K30-WS	2002	5
K30-XQ	2006	1
K30-XS	2006	1
K30-XV	1982	25
K35B-U	1985	22
K35D-U	1987	20
K35G-U	1990	17
K35J-U	1992	15
K35-KU	1993	14
K35-MU	1995	12

## 三菱扇風機 形名順 販売年度一覽表

形名	販売開始年	経過年数
K35-UT	1981	26
K35-UTB	1980	27
K35-UV	1981	26
K35-UX	1982	25
P-10B	1956	51
P-10C	1957	50
P-20AC	1958	49
P-25C	1959	48
P-8A	1957	50
P-8AB	1957	50
PF-45HNNH	1985	22
PF-45JKH	1985	22
PF-45JQH	1985	22
PF-45JSH	1985	22
R-12A	1957	50
R-12AB	1958	49
R25-S	1963	44
R25-S2	1964	43
R25-S5	1965	42
R305-BR	1985	22
R305-WB	1986	21
R305-WG	1986	21
R306-BG	1985	22
R306-BP	1985	22
R308-BGY	1988	19
R308-BMB	1988	19
R-30AB	1959	48
R-30AC	1959	48
R-30AD	1958	49
R30-AE	2005	2
R30A-F	1984	23
R30A-H	1984	23
R30-AHR	2006	1
R30-AM	2006	1
R30-AMG	2007	0
R30-AR	2006	1
R30-ARG	2007	0
R30A-W	1984	23
R30B-H	1985	22
R30B-W	1985	22
R30B-X	1985	22
R30B-Y	1985	22
R-30C	1959	48
R30C-E	1986	21
R30C-F	1986	21
R30C-H	1986	21
R30C-W	1986	21
R30C-X	1986	21
R-30D	1960	47
R30D-K	1987	20
R30-DT	1981	26
R30D-T	1987	20
R30-DTG	1980	27
R30-DV	1981	26
R30-DW	1986	21
R30D-W	1987	20
R30D-X	1987	20
R30D-Z	1987	20
R-30E	1960	47
R-30EB	1961	46
R-30EC	1961	46
R30E-D	1988	19
R30-EV	1981	26
R30E-WBU	1988	19
R30-EX	1982	25

形名	販売開始年	経過年数
R30-F	1979	28
R30-F2	1979	28
R30-FB	1973	34
R30F-B	1989	18
R30F-D	1989	18
R30-FTK	1980	27
R30-FTL	1980	27
R30-FV	1981	26
R30-FX	1982	25
R30F-Y	1989	18
R30-FZ	1983	24
R-30G	1961	46
R30G-B	1990	17
R30G-D	1990	17
R30-GL	1978	29
R30-GL2	1979	28
R30-GR	1978	29
R30-GR2	1979	28
R30-GX	1977	30
R30G-Y	1990	17
R-30H	1961	46
R30H-B	1991	16
R30H-D	1991	16
R30-HRB	2001	6
R30-HRC	2002	5
R30-HRE	2004	3
R30-HRF	2005	2
R30-HRH	2007	0
R30-HT	1981	26
R30-HTB	1980	27
R30-HTG	1980	27
R30-HV	1981	26
R30-HX	1982	25
R30-HY	1981	26
R30H-Y	1991	16
R30-HZ	1983	24
R-30J	1962	45
R30J-B	1992	15
R30J-D	1992	15
R30J-Y	1992	15
R30-KB	1993	14
R30-KF	1993	14
R30-KV	1981	26
R30-KW	1993	14
R30-LF	1994	13
R-30M	1962	45
R30-MA	2000	7
R30-MB	2001	6
R30-MBEG	2002	5
R30-MBK	2001	6
R30-MC	2002	5
R30-MCEG	2002	5
R30-MCK	2001	6
R30-MD	2003	4
R30-ME	2004	3
R30-ME2	2005	2
R30-MF	1995	12
R30-MG	2006	1
R30-MGE3	2006	1
R30-MH	2007	0
R30-MV6D	2004	3
R30-MW	1995	12
R30-MX	1999	8
R30-NF	1996	11
R30-NW	1996	11

形名	販売開始年	経過年数
R30-RA	2000	7
R30-RB	2001	6
R30-RC	2002	5
R30-RD	2003	4
R30-RE	2004	3
R30-RF	2005	2
R30-RG	2006	1
R30-RH	2007	0
R30-RHV	2007	0
R30-RX	1999	8
R30-SB	1985	22
R30-SB2	1986	21
R30-SF	1970	37
R30-SF5	1971	36
R30-SF6	1972	35
R30-SS	1970	37
R30-SX	1968	39
R30-SX2	1969	38
R30-SX3	1970	37
R30-SX5	1971	36
R30-T	1963	44
R30-T2	1964	43
R30-T5	1965	42
R30-TF	1997	10
R30-TW	1997	10
R30-U6	1966	41
R30-U7	1968	39
R30-U8	1969	38
R30-V	1963	44
R30-VF	1998	9
R30-VRH	2007	0
R30-VT	1981	26
R30-VTK	1980	27
R30-VW	1998	9
R30-VX	1982	25
R30-W	1963	44
R30-W10	1971	36
R30-W11	1972	35
R30-W2	1964	43
R30-W5	1965	42
R30-W6	1966	41
R30-W7	1967	40
R30-W8	1968	39
R30-W9	1970	37
R30-WB	1973	34
R30-WB-M	1973	34
R30-WD	1974	33
R30-WD2	1974	33
R30-WD3	1975	32
R30-WE	1975	32
R30-WE2	1975	32
R30-WG	1976	31
R30-WG3	1978	29
R30-WK	1977	30
R30-WK2	1977	30
R30-WP	1978	29
R30-WP2	1978	29
R30-WS	1979	28
R30-WS2	1979	28
R30-WT	1981	26
R30-WTB	1980	27
R30-WTG	1980	27
R30-WV	1981	26
R30-WX	1982	25
R30-WY	1981	26

## 三菱扇風機 形名順 販売年度一覽表

形名	販売開始年	経過年数
R30-WZ	1983	24
R30-X	1963	44
R30-X10	1969	38
R30-X11	1970	37
R30-X12	1972	35
R30-X2	1964	43
R30-X3	1965	42
R30-X7	1966	41
R30-X8	1967	40
R30-X9	1968	39
R30-XB	1973	34
R30-XC	1974	33
R30-XE	1975	32
R30-XG	1976	31
R30-XK	1977	30
R30-XP	1978	29
R30-XS	1979	28
R30-XTB	1980	27
R30-XV	1981	26
R30-XX	1982	25
R30-XZ	1983	24
R30-YG	1976	31
R30-YK	1977	30
R30-YK2	1977	30
R30-YP	1978	29
R30-YP2	1978	29
R30-YS	1979	28
R30-YS2	1979	28
R30-YT	1981	26
R30-YTB	1980	27
R30-YTG	1980	27
R30-YV	1981	26
R30-Z10	1970	37
R30-Z3	1965	42
R30-Z6	1966	41
R30-Z7	1967	40
R30-Z8	1968	39
R30-Z9	1969	38
R310-B BE	1989	18
R310-B BK	1989	18
R35D-N	1987	20
R35G-N	1990	17
R35J-N	1992	15
R35-N2	1967	40
R35-N3	1968	39
R35-N5	1969	38
R35-N6	1970	37
R35-N7	1971	36
R35-N8	1972	35
R35-NB	1973	34
R35-NC	1974	33
R35-NE	1975	32
R35-NG	1976	31
R35-NK	1977	30
R35-NP	1978	29
R35-NS	1979	28
R35-NT	1981	26
R35-NTB	1980	27
R35-NV	1981	26
R35-NX	1983	24
R35-SN	1969	38
R35-SN2	1970	37
R35-SN3	1971	36
R35-TV	1981	26
R35-TX	1984	23

形名	販売開始年	経過年数
R35-Y	1963	44
R35-Y10	1970	37
R35-Y2	1964	43
R35-Y5	1965	42
R35-Y6	1966	41
R35-Y7	1967	40
R35-Y8	1968	39
R35-Y9	1969	38
R40-ME	2004	3
R40-RA	2000	7
RM-25A	1959	48
RM-25AB	1960	47
RM-25B	1959	48
RM-25BB	1962	45
RM-30B	1959	48
RM-30CB	1960	47
RM-30F	1961	46
RM-30K	1962	45
RM-30L	1962	45
RM-35A	1959	48
RM-35AB	1960	47
RM-35AC	1961	46
RM-35B	1962	45
RM-35K	1962	45
S-16A	1952	55
S-16B	1953	54
S-16C	1956	51
S-16D	1957	50
S30-A	1963	44
S-30A2	1966	41
S30-A2	1964	43
S-30AC	1960	47
S-30B	1962	45
S30-K	1965	42
S40-B	1963	44
S40-B2	1964	43
S40C-M	1986	21
S-40D	1959	48
S40D-M	1987	20
S40G-M	1990	17
S40J-M	1992	15
S-40M	1966	41
S40-M2	1967	40
S40-M3	1968	39
S40-M5	1969	38
S40-M6	1970	37
S40-M7	1971	36
S40-M8	1972	35
S40-MB	1973	34
S40-MC	1974	33
S40-ME	1975	32
S40-MG	1976	31
S40-MK	1977	30
S40-MP	1978	29
S40-MS	1979	28
S40-MT	1981	26
S40-MTB	1980	27
S40-MV	1981	26
S-60A	1961	46
SM-16E	1958	49
SM-40E	1958	49
SM-40EC	1959	48
SM-40EH	1958	49
SM-40EJ	1961	46
SM-40EL	1961	46

形名	販売開始年	経過年数
SM-40F	1962	45
SM-40GBH	1962	45
SM-40GH	1962	45
Z-30EB	1974	33
Z-30EC	1974	33