


# MITSUBISHI RACK MOUNT ADAPTER DX-RM5(ZD)


## INSTALLATION TO THE EIA RACK

By using this bracket set, you can install the HDD Extension Unit to the EIA rack. Space for one unit is required for installing.


- 1 Remove 4 insulators at the bottom.  
Unscrew the screws to remove the insulators.



- 2 Remove 2 screws from one side of the Extension Unit.



- 3 Fix the bracket to the Extension Unit with the removed screws.




- 4 Fix it on the other side in the same way.
- 5 Install the Extension Unit anywhere on the EIA rack with 2 screws.
  - Use screws that fit the rack.


### INCLUDED ITEMS

- Bracket L/R x 1
- Installation manual (This sheet) x 1

- If you install the Extension Unit to the rack of universal pitch type, attach the screws as shown by (A).



- If you install the Extension Unit to the rack of wide pitch type, attach the screws as shown by (B).



- 6 Fix the other side of the Extension Unit in the same way.


### NOTE:

- Do not remove the top cover on the Extension Unit.
- When installing, be sure to turn off the Extension Unit's power and unplug the power cord from the power outlet. To protect the HDDs, do not move the Extension Unit at least one minute after the power is turned off.
- Do not place heavy objects on the Extension Unit after installing the Extension Unit to the rack.


## EIAラックへの取り付けかた

本セットを使って、デジタルレコーダー増設ユニットをEIAラックの1ユニット分に取り付けることができます。


- 1 増設ユニットの脚を取りはずす。  
ネジははずし、脚を取りはずしてください。



- 2 増設ユニット側面のネジ2本ははずす。



- 3 はずしたネジを使って、ブラケットを増設ユニットに取り付ける。




- 4 反対側も同様に取り付け。
- 5 EIAラックのお好みの位置に、増設ユニットをネジ止めて取り付け。
  - ネジは、ラックに合わせてご用意ください。


### 同梱部品

- ブラケット： 左右一式
- 取付説明書(本シート)： 1枚

- ユニバーサルピッチのラックに取り付ける場合は、ネジを(A)の位置に取り付けてください。



- ワイドピッチのラックに取り付ける場合は、ネジを(B)の位置に取り付けてください。



- 6 反対側も同様に取り付け。

### お願い：

- 増設ユニットのトップパネルは、はずさないでください。
- 取り付けるときは、必ず増設ユニットの電源を切り、電源プラグをコンセントから抜いて、作業してください。HDDを保護するため、電源を切ってから少なくとも1分間は増設ユニットを移動させないでください。
- 増設ユニットをラックに取り付けたあとは、増設ユニットの天面に荷重を加えないでください。