

## TECHNICAL BULLETIN

[Issue No.] T10-0013

[Page] 1/1

[Title] Password for self-diagnosis user area check

[Date of Issue] October '99

[Relevant Models] GOT800 Series, GOT-A900 Series

Thank you for your continued patronage of the Mitsubishi graphic operation terminal MELSEC-GOT Series.

The display of the execution password value, displayed on the GOT screen during the self-diagnosis user area check has been removed from the following software packages.

### Whereas

[Details]

#### ● Relevant software package

SW3NIW-A8SYSP Version R and above  
SW2D5C-GOTRE-PACK Version C and above

When the user area check is carried out, all of the GOT user memory is erased.

Thus, with the conventional self-diagnosis user area check with which the password was displayed on the GOT screen, there was a chance that the screen data could be lost by the user's careless executions.

By removing the password display (Input "1111") from the GOT screen, careless execution can be prevented, thereby preventing the loss of screen data.

When executing the user area check, input "1111" on the password input screen in the same manner as the conventional check.

(The display "Input "1111"" has been removed from the GOT screen, but the GOT user memory can be erased by inputting the password "1111".)



**MITSUBISHI ELECTRIC CORPORATION**

HEAD OFFICE MITSUBISHI DENKI BLDG. MARUNOUCHI. TOKYO 100-0005. TELEX J24532 CABLE MELCO TOKYO