



## TECHNICAL BULLETIN

[ 1 / 9 ]

[Issue No.] GOT-A-0070-D

[Title] List of Valid Devices Applicable for GOT2000 Series MODBUS Connection

[Date of Issue] January 2014 (Ver. D: April 2019)

[Relevant Models] GOT2000 Series

Thank you for your continued support of Mitsubishi Electric Graphic Operation Terminal (GOT). This bulletin provides information on the MODBUS equipment that has been validated for connection with the GOT2000 series. Regarding the production status and the specifications of each product, confirm with the manufacturer.

### Recommended Product

Products that are compliant with Mitsubishi Electric standards.  
Use Recommended Products according to their specifications.

### Compatible Product

Products that are connectable to Mitsubishi Electric products.  
(Note that compatibility is not verified by Mitsubishi Electric.)  
Use Compatible Products according to their specifications.

Some Compatible Products may not be connected because their specifications have changed depending on the date of manufacture.

Verify Compatible Products, and determine whether or not to use the products.

### Discontinued Product

Recommended Products or Compatible Products that have been mentioned in the bulletin before, but may be difficult to procure because they have been discontinued.

### Incompatible Product

Products that are not connectable to Mitsubishi Electric products.  
Use Compatible Products.

## Contents

1.	Overview .....	2
2.	Precautions .....	3
2.1	Connectable MODBUS equipment .....	3
2.2	Device specification method .....	3
2.3	Connection check of the MODBUS equipment .....	3
2.4	MODBUS communication control function (When the communication driver is the MODBUS/RTU master, MODBUS/TCP master, or gateway) .....	3
3.	List of the equipment validated for the MODBUS/RTU master connection .....	4
3.1	Example of connecting the equipment manufactured by Mitsubishi Electric Corporation .....	4
3.2	Example of connecting the equipment manufactured by Azbil Corporation .....	4
3.3	Example of connecting the equipment manufactured by Yokogawa Electric Corporation .....	5
3.4	Example of connecting the equipment manufactured by SMC Corporation .....	5
3.5	Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd. ....	5
4.	List of the equipment validated for the MODBUS/TCP master connection .....	6
4.1	Example of connecting the equipment manufactured by Azbil Corporation .....	6
4.2	Example of connecting the equipment manufactured by Schneider Electric .....	6
4.3	Example of connecting the equipment manufactured by Yokogawa Electric Corporation .....	6
4.4	Example of connecting the equipment manufactured by RKC Instrument Inc. ....	7

## MITSUBISHI ELECTRIC CORPORATION

HEAD OFFICE : TOKYO BUILDING, 2-7-3 MARUNOUCHI, CHIYODA-KU, TOKYO 100-8310, JAPAN  
NAGOYA WORKS : 1-14, YADA-MINAMI 5-CHOME, HIGASHI-KU, NAGOYA, JAPAN

4.5 Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd..... 7

5. List of the equipment validated for the MODBUS/RTU slave connection..... 7

5.1 Example of connecting the equipment manufactured by Mitsubishi Electric Corporation ..... 7

5.2 Example of connecting the equipment manufactured by Schneider Electric ..... 7

5.3 Example of connecting the equipment manufactured by Yokogawa Electric Corporation..... 8

5.4 Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd..... 8

6. List of the equipment validated for the MODBUS/TCP slave connection..... 8

6.1 Example of connecting the equipment manufactured by Mitsubishi Electric Corporation ..... 8

6.2 Example of connecting the equipment manufactured by Yokogawa Electric Corporation..... 8

6.3 Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd..... 9

7. Appendix..... 9

7.1 Function code ..... 9

REVISIONS..... 9

**1. Overview**

With a MODBUS/RTU or MODBUS/TCP communication driver, the GOT2000 series can communicate with the equipment that supports the MODBUS connection.

The GOT2000 series can be operated as either the master station or the slave station.

Table 1-1 shows the applicable communication drivers by GOT model.

Table 1-1 Applicable communication drivers by GOT model

Connection type	Communication type	Communication driver	GT27	GT25	GT23	GT SoftGOT2000	GT Simulator3
MODBUS/RTU master connection	RS-232	MODBUS/RTU Master	Supported	Supported	Supported	Not supported	Not supported
	RS-422/485						
MODBUS/TCP master connection	Ethernet	MODBUS/TCP Master, Gateway	Supported	Supported	Supported	Supported	Not supported
MODBUS/RTU slave connection	RS-232	MODBUS/RTU Slave	Supported	Supported	Supported	Not supported	Not supported
	RS-422/485						
MODBUS/TCP slave connection	Ethernet	MODBUS/TCP Slave, Gateway	Supported	Supported	Supported	Supported	Not supported

For the setting to connect the MODBUS equipment with the GOT2000 series, refer to the following.

- GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1
- 5. MODBUS/RTU MASTER CONNECTION
- 6. MODBUS/TCP MASTER CONNECTION
- 7. MODBUS/RTU SLAVE CONNECTION
- 8. MODBUS/TCP SLAVE CONNECTION

**2. Precautions**

**2.1 Connectable MODBUS equipment**

For the relationship between the communication drivers and the connectable MODBUS equipment, refer to table 2-1.

Table 2-1 Connectable MODBUS equipment

Software	Communication driver	Connectable MODBUS equipment
GT Designer3 Version1 (GOT2000)	MODBUS/RTU Master	General MODBUS/RTU slave equipment
	MODBUS/TCP Master, Gateway	General MODBUS/TCP slave equipment
	MODBUS/RTU Slave	General MODBUS/RTU master equipment
	MODBUS/TCP Slave, Gateway	General MODBUS/TCP master equipment


**2.2 Device specification method**

The following shows the address representation on GT Designer3 Version1 (GOT2000).

- The address number is displayed in decimal format.
- The address number starts from 1.

Therefore, when the GOT monitors the holding register's address "1234H", "404661" is displayed on GT Designer3 Version1 (GOT2000).

Figure 1 Device specification



For the details of the device specification method, refer to the following.

- GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1
  - 5.6 Device Range that Can Be Set ■3. Address
  - 6.5 Device Range that Can Be Set ■3. Address

**2.3 Connection check of the MODBUS equipment**

When the communication driver (MODBUS/RTU master) is used, the GOT2000 series regularly reads the holding register 400001 to check the communication with the MODBUS equipment.

If the GOT2000 series communicates with the MODBUS equipment that does not have the holding register 400001, a communication error may occur in the equipment.

**2.4 MODBUS communication control function**

**(When the communication driver is the MODBUS/RTU master, MODBUS/TCP master, or gateway)**

The function codes and the maximum data transfer size of each function code differ according to the MODBUS equipment. This function enables you to select a function code and set the maximum data transfer size of the function code.

Set the MODBUS communication control function according to the connected MODBUS equipment.

You can set this function in the communication detail settings, or with the GS device.

When you set this function both in the communication detail settings and with the GS device, the setting with the GS device has higher priority.

You are recommended to preset this function in the communication detail settings.

For the details of the MODBUS communication control function, refer to the following.

- GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1
  - 5.6 Device Range that Can Be Set ■3. MODBUS communication control function on the GS device
  - 5.7 Precautions ■5. MODBUS communication control function on the GS device
  - 6.3.2 Communication detail settings
  - 6.5 Device Range that Can Be Set ■3. MODBUS communication control function on the GS device
  - 6.7 Precautions ■4. MODBUS communication control function on the GS device

**3. List of the equipment validated for the MODBUS/RTU master connection**

Table 3-1 shows the MODBUS/RTU slave equipment that has been validated for the MODBUS/RTU master connection.

Table 3-1 MODBUS/RTU slave equipment (Compatible Product)

Manufacturer	Model	Detailed connection example
Mitsubishi Electric Corporation	Energy measuring module EcoMonitorPlus EMU4-BM1-MB, EMU4-HM1-MB, EMU4-LG1-MB	Refer to 3.1
	Energy measuring module EcoMonitorLight EMU4-BD1-MB, EMU4-HD1-MB	
	Electronic multi-measuring instrument EM series ME110SSR-MB, ME96NSR-MB	
Azbil Corporation	NX series NX-D15, NX-D25, NX-D35, NX-DX1, NX-DX2, NX-DY1, NX-S01, NX-S11, NX-D12, NX-S21	Refer to 3.2
Yokogawa Electric Corporation	μR series μR10000, μR20000	Refer to 3.3
	DXAdvanced DX1000, DX2000	
	YS1000 series YS1700, YS1500	
	DAQMASTER MW100	
	SMARTDAC+ GX20, GX10, GP20, GP10, GM10	
SMC Corporation	LECP6, LECA6	Refer to 3.4
Hitachi Industrial Equipment Systems Co., Ltd.	EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	Refer to 3.5

**3.1 Example of connecting the equipment manufactured by Mitsubishi Electric Corporation**

Series	Communication module	Communication type	Connection cable
Energy measuring module *1 EcoMonitorPlus EMU4-BM1-MB, EMU4-HM1-MB, EMU4-LG1-MB	—	RS-485	Refer to the GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1 and the manual of the MODBUS equipment.
Energy measuring module *1 EcoMonitorLight EMU4-BD1-MB, EMU4-HD1-MB			
Electronic multi-measuring instrument EM series ME110SSR-MB, ME96NSR-MB			

\*1 After writing the data of the GOT to the set registers, wait for five seconds or more before monitoring the set values or resetting the values.  
Not waiting for five seconds or more may cause system alarm 401 to occur.  
Even if 401 occurs, data are written to the set registers.  
To reset the alarm, turn on the GOT Error Reset signal (System signal 1-1.b13).

**3.2 Example of connecting the equipment manufactured by Azbil Corporation**

Series	Communication module	Communication type	Connection cable
NX series NX-D15, NX-D25, NX-D35, NX-DX1, NX-DX2, NX-DY1, NX-S01, NX-S11, NX-D12, NX-S21	—	RS-485	Refer to the GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1 and the manual of the MODBUS equipment.

**3.3 Example of connecting the equipment manufactured by Yokogawa Electric Corporation**

Series	Communication module	Communication type	Connection cable
μR series μR10000 μR20000	—	RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Refer to 8.3.2 RS-485 cable in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1.
DXAdvanced DX1000 DX2000	—	RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Refer to 8.3.2 RS-485 cable in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1.
YS1000 series YS1700 YS1500	—	RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Use a GT09-C□□R40303-6T cable, or refer to 8.3.2 ■1. (3) RS-485 connection diagram 3) in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1
DAQMASTER MW100	—	RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Refer to 8.3.2 RS-485 cable in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1.
SMARTDAC+ GX20 GX10 GP20 GP10	—	RS-232	Refer to the GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1 and the manual of the MODBUS equipment.
		RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Refer to 8.3.2 RS-485 cable in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1.
SMARTDAC+ GM10	—	RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Refer to 8.3.2 RS-485 cable in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1.

**3.4 Example of connecting the equipment manufactured by SMC Corporation**

Series name	Communication module	Communication type	Connection cable
LECP6, LECA6	—	RS-485	Refer to the GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1 and the manual of the MODBUS equipment.

**3.5 Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd.**

Series	Communication module	Communication type	Connection cable
EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	EH-SIO	RS-422/485	Refer to the GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1 and the manual of the MODBUS equipment.
		RS-232	

**4. List of the equipment validated for the MODBUS/TCP master connection**

Table 4-1 shows the MODBUS/TCP slave equipment that has been validated for the MODBUS/TCP master connection.

Table 4-1 MODBUS/TCP slave equipment (Compatible Product)

Manufacturer	Model	Detailed connection example
Azbil Corporation	NX series NX-D15, NX-D25, NX-D35, NX-DX1, NX-DX2, NX-DY, NX-S01, NX-S11, NX-S12, NX-S21	Refer to 4.1
Schneider Electric	Modicon Premium series	Refer to 4.2
	Modicon Quantum series	
	Twido series	
Yokogawa Electric Corporation	STARDOM	Refer to 4.3
	DXAdvanced DX1000, DX2000	
	UTAdvanced series	
	DAQMASTER MW100	
	SMARTDAC+ GX20, GX10, GP20, GP10, GM10	
RKC Instrument Inc	COM-JL	Refer to 4.4
Hitachi Industrial Equipment Systems Co., Ltd.	EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	Refer to 4.5

**4.1 Example of connecting the equipment manufactured by Azbil Corporation**

Series	Communication module	Communication type	Connection cable
NX series NX-D15, NX-D25, NX-D35, NX-DX1, NX-DX2, NX-DY1, NX-S01, NX-S11, NX-D12, NX-S21	NX-CB1	Ethernet	Category 5e or later of unshielded twisted pair cable (UTP)

**4.2 Example of connecting the equipment manufactured by Schneider Electric**

Series	Communication module	Communication type	Connection cable
Modicon Premium series	TSX ETY 4102 TSX ETY 5102	Ethernet	Shielded twisted pair cable (STP) or category 3, 4, or 5 of unshielded twisted pair cable (UTP)
Modicon Quantum series	140 NOE 771 00 140 NOE 771 10 140 NWM 100 00		
Twido series	—		

**4.3 Example of connecting the equipment manufactured by Yokogawa Electric Corporation**

Series	Communication module	Communication type	Connection cable
STARDOM	—	Ethernet	Shielded twisted pair cable (STP) or category 3, 4, or 5 of unshielded twisted pair cable (UTP)
DXAdvanced DX1000 DX2000	—	Ethernet	Category 3, 4, or 5 of unshielded twisted pair cable (UTP)
UTAdvanced series *1	—	Ethernet	Shielded twisted pair cable (STP) or category 3, 4, or 5 of unshielded twisted pair cable (UTP)
DAQMASTER MW100	—	Ethernet	Shielded twisted pair cable (STP) or category 3, 4, or 5 of unshielded twisted pair cable (UTP)
SMARTDAC+ GX20 GX10 GP20 GP10 GM10	—	Ethernet	Shielded twisted pair cable (STP) or category 3, 4, or 5 of unshielded twisted pair cable (UTP)

\*1 Set the PLC No. to 1 in the Ethernet setting on GT Designer3 Version1 (GOT2000). Do not set the host station.

**4.4 Example of connecting the equipment manufactured by RKC Instrument Inc.**

Series	Communication module	Communication type	Connection cable
COM-JL *1	—	Ethernet	Shielded twisted pair cable (STP) or category 3, 4, or 5 of unshielded twisted pair cable (UTP)

\*1 Ethernet communication converter COM-JL is used for connecting an RKC controller (SRZ series, FB series, or SRJ series). For more information on how to connect, refer to the manual of the RKC controller used.

**4.5 Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd.**

Series	Communication module	Communication type	Connection cable
EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	—	Ethernet	Shielded twisted pair cable (STP) or category 3, 4, or 5 of unshielded twisted pair cable (UTP)

**5. List of the equipment validated for the MODBUS/RTU slave connection**

Table 5-1 shows the MODBUS/RTU master equipment that has been validated for the MODBUS/RTU slave connection.

Table 5-1 MODBUS/RTU master equipment (Compatible Product)

Manufacturer	Model	Detailed connection example
Mitsubishi Electric Corporation	MELSEC-Q series MELSEC-FX series	Refer to 5.1
Schneider Electric	Twido series	Refer to 5.2
Yokogawa Electric Corporation	SMARTDAC+ GX20, GX10, GP20, GP10, GM10	Refer to 5.3
Hitachi Industrial Equipment Systems Co., Ltd.	EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	Refer to 5.4

**5.1 Example of connecting the equipment manufactured by Mitsubishi Electric Corporation**

Series	Communication module	Communication type	Connection cable
MELSEC-Q series	QJ71MB91	RS-232, RS-422/485	*1
MELSEC-FX series	FX3U-232ADP-MB	RS-232	
	FX3U-485ADP-MB	RS-422/485	

\*1 For the connection cable, refer to the following manual.

→ GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1

**5.2 Example of connecting the equipment manufactured by Schneider Electric**

Series	Communication module	Communication type	Connection cable
Twido series	TWDLMDA20DRT	RS-232	Multifunction communication cable (TSXPCX1031)



**5.3 Example of connecting the equipment manufactured by Yokogawa Electric Corporation**

Series	Communication module	Communication type	Connection cable
SMARTDAC+ GX20 GX10 GP20 GP10	—	RS-232	Refer to the GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1 and the manual of the MODBUS equipment.
		RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Refer to 8.3.2 RS-485 cable in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1.
SMARTDAC+ GM10	—	RS-485	Between the GOT and the YOKOGAWA product, the polarity of poles A and B in signal names are reversed. Refer to 8.3.2 RS-485 cable in the GOT2000 Series Connection Manual (Non-Mitsubishi Electric Products 2) For GT Works3 Version1.

**5.4 Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd.**

Series	Communication module	Communication type	Connection cable
EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	EH-SIO	RS-422/485	Refer to the GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1 and the manual of the MODBUS equipment.
		RS-232	

**6. List of the equipment validated for the MODBUS/TCP slave connection**

Table 6-1 shows the MODBUS/TCP master equipment that has been validated for the MODBUS/TCP slave connection.

Table 6-1 MODBUS/TCP master equipment (Compatible Product)

Manufacturer	Model	Detailed connection example
Mitsubishi Electric Corporation	MELSEC-Q series	Refer to 6.1
Yokogawa Electric Corporation	SMARTDAC+ GX20, GX10, GP20, GP10, GM10	Refer to 6.2
Hitachi Industrial Equipment Systems Co., Ltd.	EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	Refer to 6.3

**6.1 Example of connecting the equipment manufactured by Mitsubishi Electric Corporation**

Series name	Communication module	Communication type	Connection cable
MELSEC-Q series	QJ71MT91	Ethernet	*1

\*1 For the connection cable, refer to the following manual.

→ GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1

**6.2 Example of connecting the equipment manufactured by Yokogawa Electric Corporation**

Series	Communication module	Communication type	Connection cable
SMARTDAC+ GX20 GX10 GP20 GP10 GM10	QJ71MT91	Ethernet	*1

\*1 For the connection cable, refer to the following manual.

→ GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1



[Issue No.] GOT-A-0070-D

**6.3 Example of connecting the equipment manufactured by Hitachi Industrial Equipment Systems Co., Ltd.**

Series	Communication module	Communication type	Connection cable
EHV series EHV-CPU16, EHV-CPU32, EHV-CPU64, EHV-CPU128, EHV-CPR128	—	Ethernet	*1

\*1 For the connection cable, refer to the following manual.

→ GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1

**7. Appendix****7.1 Function code**

For the function codes (sub function codes) supported by the GOT, refer to the following manual.

→ GOT2000 Series Connection Manual (Microcomputers, MODBUS/Fieldbus Products, Peripherals) For GT Works3 Version1

**REVISIONS**

Version	Print Date	Revision
-	January 2014	- First edition
A	February 2017	- The MODBUS slave connection is supported.
B	January 2018	- The equipment validated for the MODBUS/RTU master connection has been added. - The equipment validated for the MODBUS/TCP master connection has been added. - The equipment validated for the MODBUS/RTU slave connection has been added. - The equipment validated for the MODBUS/TCP slave connection has been added.
C	May 2018	- The RKC controllers validated for the MODBUS/TCP master connection have been added.
D	April 2019	- Mitsubishi Electric equipment validated for the MODBUS connection has been added. - Hitachi Industrial Equipment Systems equipment validated for the MODBUS connection has been added.

**■ Trademarks**

Product and company names are either trademarks or registered trademarks of their respective owners.